

User Interface


Programmable Keys

Your phone has four programmable function keys with status LEDs.




Operating instructions can be found on the back.


Fixed Function Keys



5-Way Navigator



Audio keys



Notification LED

With the Notification LED different phone status can be identified:

- Off: Idle
- Green solid: Active call
- Green pulsing: Incoming call
- Amber solid: Call(s) on hold
- Amber pulsing: Held call re-presenting
- Red solid: New missed call
- Red pulsing: New voicemail (MWI)

Unify OpenScape Desk Phone CP210

HFA

Quick Reference Card

mitel.com



© 2024 Mitel Networks Corporation. All Rights Reserved. Mitel and the Mitel logo are trademark(s) of Mitel Networks Corporation. Unify and associated marks are trademarks of Unify Software and Solutions GmbH & Co. KG. All other trademarks herein are the property of their respective owners.

09/2024



Sachnummer: A31003-C1000-U139-2-7619

Using your Unify OpenScape Desk Phone CP210



Place a Call

- Lift handset, dial number or
- Dial number and lift handset or
- For handsfree mode or if headset is connected: dial number.

Answer a Call


- Lift handset or
- for handsfree mode: press  or
- if headset is connected: press .

End a Call

- Hang up, or
- For handsfree mode: press  or
- If headset is connected: press .

Open listening

During a call with handset:


- Press .

Switch off open listening:

- Press .

Switch between Handset and Handsfree Mode

Switch to handsfree mode during a Call:



- Hold down  until you hang up handset.

Switch to handset:

- Lift handset.

Hold and Retrieve a Call



During a call with Party A:

- Press . Party A is put on hold.
- To retrieve a held call: press  again (OpenScape 4000: select retrieve from context menu).

Using your Unify OpenScape Desk Phone CP210

Consultation





During a call with Party A:

1. Press . Party A is put on hold.
2. Call Party B.
3. If the conversation with Party B is finished, press  or wait, until Party B has hang up.

You are now connected again to Party A.



Toggle

During a call with Party A:

1. Press . Party A is put on hold.
2. Call Party B.
3. If connected to Party B, press  and  to toggle. Pressing  repeatedly toggles between Party A and B.



Make a Conference Call

During a call with Party A:


1. Press . Party A is put on hold.
 2. Call Party B.
 3. If connected to Party B, press .
- You are now in a conference call with Party A and B.

Transfer a Call

During a call with Party A:

1. Press . Party A is put on hold.
2. Call Party B.
3. If connected to Party B, press . Alternatively, the call can be transferred without consultation (blind transfer). The party A will be transferred to Party B.

Call back





1. Call an internal Party. The Party does not lift the handset or is busy.
2. Press . the call back is activated.
3. As soon as the not reached Party has hung up, the callback is triggered and your telephone rings.
4. Answer the call back. The not reached Party is called.

Programmable keys










Call log Phonebook Call forwarding Redial




Call log

1. Press .
2. Press  to show the entries.
3. Press  and  to select additional functions like:
 - show time,
 - call number or
 - delete entry

Phone book (OpenScape Business) ¹

1. Press .
2. Pressing digit keys on the dialpad several times: Limit the list of names in the phone book to the desired initial letters, example:
1x   2x   1x   searches for „PET“ at the beginning of the word.
3. Scroll through the list by .
4. Press  to show the entry.

Call Forwarding




- Press . Calls will forwarded to the programmed destination.

To switch off the call forwarding:

- Press  again.

Redial

Dials one of the stored external numbers.

1. Press .
2. Scroll through the list by .
3. Press  to call the number.

For programming the keys see the user manual.

1. For the procedure on OpenScape 4000 see the user manual.