

TAKE A BACKUP OF PM/SNM

When you have performed the installation and after making changes in PM and SNM, it is a good idea to take a backup of the settings.


LOG IN TO MP

Do as follows:

1. Open **MX-ONE Provisioning Manager (PM)**. The start page is displayed.
2. Type the **User name** in the field **User**.
3. Type the **Password** in the field **Password**.
4. Click **Login**. The main page is displayed.

TAKE A BACKUP OF MP

Do as follows:


1. Click **System** and then **Data Management**. A menu to the left is displayed.
2. Click **Backup & Restore**. The **Backup & Restore** page is displayed.
3. Click **Backup**. The **Backup & Restore – Backup** page is displayed.
4. Click **Apply**.
5. To save the backup, click **Download**, . The **File download** page is displayed.
6. Click **Save**. The **Save as** window is displayed.
7. Select location from the list **Save in**.
8. Click **Save**.

TAKE A BACKUP SNM

Do as follows:

1. Click **System** and then **Subsystem**. The **Subsystem** page is displayed.
2. Click **SN**. The **MX-ONE Service Node Manager (SNM)** page is displayed.
3. Click **System** and then **Backup & Restore**. The **Backup & Restore** page is displayed.
4. Click **Backup**.
5. If the backup was successful, you get the following message:

Backup & Restore



Backup