



Mitel 6940 SIP Phone for MX-ONE

QUICK REFERENCE GUIDE

Important User Information

NOTICE

The information contained in this document is believed to be accurate in all respects but is not warranted by Mitel Networks™ Corporation (MITEL®). Mitel makes no warranty of any kind with regards to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. The information is subject to change without notice and should not be construed in any way as a commitment by Mitel or any of its affiliates or subsidiaries. Mitel and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from Mitel Networks Corporation.

TRADEMARKS

The trademarks, service marks, logos and graphics (collectively "Trademarks") appearing on Mitel's Internet sites or in its publications are registered and unregistered trademarks of Mitel Networks Corporation (MNC) or its subsidiaries (collectively "Mitel") or others. Use of the Trademarks is prohibited without the express consent from Mitel. Please contact our legal department at legal@mitel.com for additional information. For a list of the worldwide Mitel Networks Corporation registered trademarks, please refer to the website: <http://www.mitel.com/trademarks>.

© Copyright 2017, Mitel Networks Corporation
All rights reserved

Notice to European customers:

For complete safety notice see the document
Installation Guide Mitel MiVoice 6920 IP Phone.

Safety Instructions

Save these instructions.

Read these safety instructions before use!

Note: When using your telephone or connected equipment, the following basic safety precautions should always be followed to reduce risk of fire, electrical shock and other personal injury.

- Follow instructions in the equipment's user guide or other documentation.
- Always install equipment in a location and environment for which it is designed.
- For mains powered telephones: Only operate with the mains power voltage indicated. If you are uncertain of the type of power supplied to the building, consult property management or your local power company.
- For mains powered telephones: Avoid placing the telephone's power cable where it can be exposed to mechanical pressure as this may damage the cable. If the power supply cord or plug is damaged, disconnect the product and contact qualified service personnel.
- Headsets used with this equipment must comply with EN/IEC 60950-1 and for Australia AS/NZS 60950.1-2003.
- Do not make any changes or modifications to equipment without seeking approval from the party responsible for compliance. Unauthorized changes or modifications could void the user's authority to operate the equipment.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, and kitchen sink, in a wet basement or near a swimming pool.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Do not disassemble the product. Contact a qualified service agency when service or repair work is required.
- Do not use a telephone (other than cordless type during an electrical storm).

Disposal of the product

Your product should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

Power Adapters

The phone can be powered either from a 48 V DC power adapter (sold separately) or via the network PoE according to IEEE 802.3af.


- 50006814 (Universal)
- 50006824 (Europe)
- 50006822 (North America)

Mitel 6940

Quick Reference Guide

This Quick Reference Guide includes short descriptions on how to use the basic features with an MiVoice MX-ONE system. More features and technical details are available in the User Guide.

Read the safety instructions before use!



Phone keys

- 1 Goodbye Key
- 2 Redial Key
- 3 Hold Key
- 4 Mute Key
- 5 Speaker/Headset
- 6 Contacts
- 7 Call History
- 8 Voice Mail
- 9 Settings
- 10 Volume
- 11 LCD Touchscreen
- 12 Top Softkeys
- 13 Bottom Softkeys
- 14 Speaker
- 15 Message Waiting Indicator (MWI)

User Interface UI



Home Screen

The home screen displays the date and time along with various important status. It is the default screen when the phone is in idle state.



Line selection Screen

Allows you to easily view the lines in use and select a line to act upon.



Multi view call screen

Allows you to manage your calls more efficiently when you have more than one call in progress.



Detailed-view call screen

All information available for a specific call. It is the default screen for all point-to-point calls.

Swipe left and right in the top softkey area to switch softkey pages.

Status Indicators

- Phone Lock
- Voice mail
- Do Not Disturb
- Call Forward
- Missed Calls
- Conference call
- Incoming call
- Outgoing call
- On hold

Navigation

Navigation



Swipe left or right in the top softkey area to switch Softkey pages. Swipe left and right on the area to the right of the top softkey to switch to the line and call screen.



Swipe up and down to scroll through the different lines or calls on the respective screen.

Log In and Log Out

Log On to the system

Standard Log In /log Out

- Log in:** Press the **Log In** softkey.
- Enter own extension number as Username. Press **Submit**.
- If a PIN code is initiated in MX-ONE, there will be a Password prompt. Enter your PIN code as Password and press **Submit**.
- If you do not know your extension number or your PIN, contact your system administrator.
- Your extension number and name is shown on the display when the log on is successful.
- Log Out:** Press the **LogOut** softkey. Scroll to choose if you want to keep the incoming- and outgoing call lists or not. Press **Submit** softkey.
- If the logoff is successful, the display indicates **No service**.
- Note:** If you don't clear the call lists, someone else that logs on with another extension number on your phone can see your call lists.

Log In and Log Out

Log On to the system(Continued)

Virtual DeskPhone (VDP) log In/Log Out

- Log In:** Press the **Log In** softkey.
- Enter own extension number as User name and password.
- Press **Submit**.
- Log Out:** Press the **LogOut** softkey.
- Enter own extension number as Username and password.
- Press **Submit**.

Change of PIN code





You can change the PIN code used for logging on to the telephony system.

Change the PIN code: Enter ***74*old PIN*new PIN#**

A text message on the display confirms if the change was successful.


Incoming Calls

Answer Calls

- Answer:** 
- Handsfree mode:** Press the **Line key** or .
- Answer a second incoming call:** Press the flashing line key (requires that Free on second is activated).
- Free on Second:** The function **Free on Second** is activated by default.
- Deactivate Free on Second**
 - Press **Services** softkey and select **Free on second** line.
 - Select **Deactivate**.
 - Activate Free on Second**
 - Press **Services** softkey and select **Free on second** line.
 - Select **Activate**.
- End call:**  or 

Incoming Calls

Answer Calls (Continued)

Reject call: Press  or **Ignore** softkey.

Answer a call to a monitored extension (MNS/DMN key). *The lamp at the MNS/DMN key flashes and a short ring signal may be heard.*

Press the MNS/DMN key to display the calling part (number/name)¹.

Press the MNS/DMN key to answer the call.

1. This function requires a setting in the call manager. Please contact your system administrator.

Answer a call to a monitored extension (MNS/DMN key), while you already have an ongoing call. *The lamp at the MNS/DMN key flashes and a short ring signal may be heard.*
Put the ongoing call (L1) on hold.

Press .


Press the MNS/DMN key to answer the call on L2.

Picking Up Calls

Call pick-up:  extension number. Press

Dial. Wait for a busy tone and press the **More > CallPickUp** softkey.

or

 extension number. Press

Dial. Wait for a busy tone and press **8**.

France: **0**, Sweden: **6**, New Zealand: **4**.

Group call-pick-up: Press the **Group Monitoring** key.

Name and number of the first call is shown in the display.


Press the **Group Monitoring** key to answer the call.

or

 ***8#**

Finland and Sweden: ***0#**
U.S.A. and Canada: ***59#**

Missed Calls

Missed call indication: *Missed calls are indicated by the **Missed Call** text in the display and the missed call icon .*

Check missed calls: Press the **Recived Callers list**



Press **Missed** and check the missed calls.

Press **Quit** to exit the call list.

Outgoing Calls

Make Calls

Internal calls:  Extension number. Press

Dial.

External calls:  External access code +
External number. Press **Dial**.


Dial by contact:
(Local Directory) Press the **Directory** softkey.
Swipe up and down to scroll through the entries or enter the first letter in the name, and press an entry.

Press **Dial** .


Dial by callers list
(incoming calls): Press the **Callers** softkey.
Swipe up and down to scroll through to wanted number or name and press an entry.

Press **Dial** .

Dial by softkey
(speed dial): Press the softkey. Press **More** to get to next page with softkey.

Redial last external
number:  * * *
Press **Dial**

Finland and Sweden: * * 0

Redial from outgoing
redial list: Press .

Swipe up and down to scroll through to wanted number or name and press an entry.

Press **Dial**

Callback

The busy extension calls back when free.

Order: Press the **Callback** softkey.



or

Press **6** .



France, New Zealand, Sweden: 5

The called extension is free but does not answer.

Order: Press the **Callback** softkey.



Cancel all callbacks:  **# 37 #** Press **Dial**

Cancel single callback:  **# 37 *** Extension
number **#** .

U.S.A. and Canada: **# 6 ***

Call Waiting

A call waiting signal is sent to the busy number.

Order: Press **5** or

press **More > CallWaiting softkey.**

If you hear a ring tone, keep the handset off hook.

France, New Zealand: **6**
Sweden: **4**

Cancel call waiting: 

Call Waiting signal is indicated by CAW tones during an ongoing call.

Answer: Hang up the ongoing call, and the phone will ring for the waiting call.

Intrusion

Intrude a busy extension to ask the party to hang up.

Activate: Press **4** or

Press **More > Intrusion softkey**

France, New Zealand, Sweden: **8**

Bypass

Bypass Diversion (e.g. Follow-me) on a specific extension.

Activate:



***60* Desired number #**

U.S.A. and Canada: ***1*...**

During Calls

Put on Hold

Ongoing call: Press .

Resume a call: Press the **Pickup** softkey

Inquiry

Ongoing call: Press **Xfer** softkey, enter the number to the 3rd party. Press **L2** and wait for answer.

Switch between calls: Press the line key that holds the call you want to retrieve.

Conference

Ongoing call: Press **Xfer** softkey, enter the number to the 3rd party. Press **a free Line key** and after answer press the **More > Conference** softkey.

or

After answer press **3**

The number of participants is shown in the display.

Repeat to add more participants.

Transfer

Ongoing call: Press **Xfer** softkey, enter the number to the 3rd party. Press **L2** and press **Xfer** softkey once again (either before or after answer) to transfer the call.

Encrypted call

Ongoing call: When a padlock is shown in the display, the speech is encrypted to and from the phone.

Diversion

Follow-me

Order Follow-me and External Follow-me

Order Follow-me Press the **Diversion** softkey.

from own extension: Select **Follow-me**. Enter the new answering position number and press **More > Save**.

A confirmation text is shown in the display. The lamp at the **Diversion** softkey is lit.

Order external Press the **Diversion** softkey.

Follow-me: Select **External Follow-me**. Enter the external line code and the number. Press **Save**.

A confirmation text is shown in the display. The lamp at the **Diversion** softkey is lit.

Cancel Follow-me and External Follow-me

When diversion is active, the lamp at the **Diversion** softkey is lit.

Cancel Follow-me: Press the **Diversion** softkey.

The lamp is switched off.

Cancel External Press the **Diversion** softkey.

Follow-me: The lamp is switched off.

Individual Do Not Disturb (DND)


You can activate this feature when you do not want to be disturbed. Then anyone trying to call you will get busy or will be forwarded to the diversion position if it is defined by the system administrator.

Activate: Press the **Diversion** softkey. Select **Do Not Disurb**. "Do Not Disturb" will be shown in the display and the lamp at the Diversion key is lit.

Deactivate: Press the **Diversion** key. The lamp at the Diversion key is turned off.

Group Do Not Disturb

From an extension with a certain class of service it is possible to set do not disturb for a group of extensions. Calls to the extensions in the group will not be indicated.

Order group do not distrurb:  *** 25*group number #**

Press **Dial**.

Germany, South Africa, North America: ***28*group number#**

Cancel:  **# 25*group number #**

Press **Dial**

Germany, South Africa, North America: **#28*group number#**.

Direct Diversion/Diversion on no answer/ Diversion on busy

You can activate this feature when you want your calls to be forwarded to a predefined answering position. This feature is only available if the system administrator has enabled it.

Direct Diversion

Direct Diversion/Diversion on no answer/ Diversion on busy

Order Direct Press the **Diversion** softkey.

Diversion: Select **Direct Diversion**

Press **Select** or **>** softkey

A confirmation text with destination number is shown in the display and the **Diversion** icon is red.

or

 ***21#**
Press **Dial** .

Cancel Direct Press the **Diversion** softkey. The lamp at the Diversion softkey is switched off.

or

 **#21#**
Press **Dial** .

Diversion on no answer

Order Diversion on Press the **Diversion** softkey

no answer: Select **Div on no answer**.

The destination number is shown.

Press **Select**

or

 ***211#**
Press **Dial** .

Cancel Diversion on Press the **Diversion** softkey.
no answer:

Select **Div on no answer**.

Press **Select**

or

 **#211#**
Press **Dial** .

Direct Diversion/Diversion on no answer/ Diversion on busy

Diversion on busy

Order Diversion on busy: Press the **Diversion** softkey.
Select **Div on busy**.
The destination number is shown.

Press **Select**

or

 ***212#**
Press **Dial** .

Cancel Diversion on busy: Press the **Diversion** softkey.
Select **Div on busy**.

Press **Select**

or

 **#212#**
Press **Dial** .

Presence Information

Select absence reason: With return date / time Press the **Diversion** softkey.
Select **Presence**. Select the wanted reason for absence and enter time or date for return. Press **Set**.

A confirmation text is shown in the display. The lamp at the **Diversion** softkey is lit

Select absence reason: Without return date / time Press the **Diversion** softkey.
Select **Presence**. Select the wanted reason for absence. Press **Set**.

A confirmation text is shown in the display. The lamp at the **Diversion** softkey is lit.

Cancel: Press the **Diversion** softkey.
The lamp is switched off.

Personal Number

A number of answering positions can be defined in a personal number profile. Up to 5 profiles can be defined. You select the wanted profile from your telephone.

When somebody calls your normal office phone number the call will be announced on the telephones defined in your active profile.

The profiles can be defined by user via CMG Office Web or by the system administrator.

Order or change profile from own extension: Press the **Services** softkey.
Select **Profile**.

Select the wanted profile from the list.

#profile number or name is shown on the top row in the display, e.g. #1 or InOffice.

Deactivate: Press the **Services** softkey.

Select **No Profile**.

#profile number is removed from the top row in the display.

Advanced Features

Mobile

The key **Mobile** is used to activate the Mobile Link functionality. Mobile Link allows you to pair the deskphone with your mobile phone and to move the audio (speaker and microphone function) between the deskphone and the mobile phone (requires Bluetooth to be enabled on both phones).

Advanced Features

Mobile

Account Code(Continued)

New external call:



*** 61 * Account code**

external number.

Press **Dial**

*Norway and Finland: * 71 *...*

Ongoing
external call:

Press (Hold).

Press a free **Line** key and Dial
*** 61 * Account code #** and
wait for confirmation tone for valid
code.

Clear the line used for entering the
account code.

Press the **line** key that holds the
call.

*Norway and Finland: * 71 *...*

Advanced Features

Group Member Available (GMA)

The GMA feature allows the group member to see its actual group available status for group calls. The group number/name will be visible for the GMA-key.

Lamp indications: **Steady green light:** The member is logged in and available for group calls.

Steady red light: The member is not logged in to the group.

Steady yellow light: The member is logged in, but not available for group calls.

Authorization Code

Common Authorization Code

Dialing:



*** 72 * Authorization code #**

Press **Dial** and wait for verification tone. Dial external number.

*Canada; U.S.A: * 6 *...
Austria, Germany, The
Netherlands: * 75 *...*

Locking extension:



*** 73 * Authorization code #** Press **Dial** .

*Canada; U.S.A: * 71 *...*

Unlocking extension:



73 * Authorization code

Press **Dial** .

Individual Authorization Code

Dialing from own
extension:



*** 75 * Authorization code #**

Press **Dial** and wait for verification tone. Dial external number.

*Austria, Germany, The
Netherlands: * 72 *...*

Dialing from other
extension:



*** 75 * Authorization code * own extension number #**

Press **Dial** and wait for verification tone. Dial external number.

*Austria, Germany, The
Netherlands: * 72 *...*

Authorization Code (Continued)

Locking extension:  *** 76 *** **Authorization code #**

Press **Dial** .

Unlocking extension:  **# 76 ***
Authorization code #

Press **Dial** .

General Deactivation

Deactivate all activated features: **# 001 #**

Press **Dial**

U.S.A. and Canada: *** 0 #**

Lock

By pressing the **Lock** key the user can block the phones from being used by others until the password has been entered on the keypad.

Boss Secretary

In this section, it is assumed that a personal number list 1 (profile 1) and a personal number list 2 (profile 2) are set up in MX-ONE. Profile 1 includes the number of the secretary and is used when the feature is active. Profile 2 has not the secretary's number included.

Abbreviations:

Extension number of the boss: <Boss num>

Extension number of the secretary: <Secr num>

Personal Number: PEN

The label at the key representing the PEN key starts with a minus (-) character.

Activate the Boss *Press the PEN softkey*

Secretary feature on the secretary's telephone.

*The lamp at the PEN softkey is lit and the text **Service Requested** is shown in the display*

On the phone of the boss the personal number list with the boss secretary feature#1 is shown in the display. The lamp at the PEN key is lit.

*The calls to the boss, are announced on the secretary's telephone and the display shows **Via: <Boss num> or <Boss name>***

Deactivate the Boss *Press the PEN softkey.*

Secretary feature on the secretary's telephone.

*The lamp at the PEN softkey is turned off and the text **Service Requested** is shown in the display.*

On the phone of the boss the personal number profile without the boss secretary feature #2 is shown in the display. The lamp at the PEN key is turned off.

The calls to the boss, are announced on the telephone of the boss.

Boss Secretary(Continued)

Activate the Boss Secretary feature on the telephone of the boss.	<p><i>Press the PEN softkey.</i></p> <p><i>The text Service Requested is shown in the display and the lamp at the PEN softkey is lit.</i></p> <p><i>In the display, the active personal number list #1 is shown.</i></p> <p><i>On the secretary's telephone the lamp is lit at the PEN softkey.</i></p> <p><i>The calls to the boss, are announced on the secretary's telephone.</i></p>
Deactivate the Boss Secretary feature on the telephone of the boss.	<p><i>Press the PEN softkey.</i></p> <p><i>The text Service Requested is shown in the display and the lamp at the PEN softkey is turned off.</i></p> <p><i>In the display, the personal number profile without the boss secretary feature #2 is shown.</i></p> <p><i>On the secretary's telephone the lamp is also switched off at the PEN softkey.</i></p> <p><i>The calls to the boss, are announced on the telephone of the boss.</i></p>

Monitoring of Extensions

Monitoring of Extensions (MNS)

Other extensions can be monitored from softkeys on your telephone. The monitoring keys are called MNS keys.

When the monitored extension is busy the field is lit in red, and if the extension is free the field is lit in green.

Answer a call to the monitored extension. *The lamp at the MNS softkey is flashing. Press the softkey to answer the call.*

Monitoring of Extensions(Continued)

Diversion/Deflect Monitoring (DMN)

Calls that are Diverted or Deflected from your phone can be monitored from a softkey on your phone. This monitoring key is called DMN.

Shared Call Appearance (SCA)

The SCA feature allows a group of terminals to control the incoming and outgoing calls on a common line.

Your extension number can be represented on a SCA key on other extensions in your work group. Any member can answer calls to your SCA line and make outgoing calls on the SCA line.

A member that have an active call, can put the call on hold and it can be retrived from any member in the group. This is a simple way to exchange/move calls between the members.

Any member in the work group can initiate a by barge into an active SCA line. This feature is enabled by the system administrator.

If your phone is monitoring other members with SCA lines, these SCA lines are represented on softkeys.

Lamp indications:

Main rule: Green light when it is your call. Red light when somebody else in the SCA group has the active call. This is valid for the L1 and L2keys but when a SCA line is represented on a softkey, only red light can be shown. The table below describes the L1-L2 keys:

Steady green light:	<i>Active call. You are the owner of the call.</i>
Steady red light	<i>Active call. Somebody else in the SCA group is the owner of the call.</i>
Fast flashing green light:	<i>Incoming call. Anyone in the SCA group can answer the call.</i>
Slow flashing green light	<i>Parked call. You have parked the call from your terminal.</i>


Shared Call Appearance

Slow flashing red light *Parked call. Somebody else in the SCA group has parked the call.*

Traffic cases:

Answer an incoming call on a SCA line *Press the **SCA** key that is flashing (green fast flashing).*

Make an outgoing call from a SCA line: *Press the **SCA** key, enter the digits and press **Dial***

Park and retrieve the call *The member that has the active call presses . The **SCA** key flashes slowly with green light.*

*Any member in the group can retrieve the call by pressing the **SCA** key that is flashing slowly with red light.*

Conferencing *A member in the group wants to participate in an active call. The member presses the **SCA** key with the active call indicated with red steady light. (The feature has to be enabled by the system administrator).*

Extra Directory Number (EDN)

The system administrator can assign one or several extra directory numbers (lines) to your telephone. The extra directory number is represented on a line key or a softkey.

Make a call from a EDN line: *Press the wanted **EDN** line or softkey. Enter the number, press **Dial**.*

Answer a call to an EDN line: *Press the **EDN** key that is flashing.*

Call Park Pool

You can park a call and transfer the call at a specific directory number (also called Call Park Pool) and any extension can pick up the call. If the call is not picked up within a few minutes, the call will recall your extension.

Transfer the call to the call park pool: *You have an active call. Press the **Xfer** softkey to put the call on hold. Dial the number to the call park pool. Note the number (here called B-number) that shows up on the display. Press the **Xfer** softkey to transfer the call.*

Inform the person that shall take the call that he/she shall pickup the call on the number (B-number).

Pick up a call that is parked in the call park pool *Dial the B-number that you received from your colleague. When you hear the busy tone press **More > CallPickUp** short key to pick up the call*

Intercom


The system administrator can initiate an intercom connection on a softkey on your phone. When you press the key, a call is set up towards a predefined party and it is answered automatically.

Initiate an Intercom call: *Press the Intercom softkey.*

Answer an Intercom call *The Intercom key is flashing, a ring signal is heard and the call is answered automatically.*

You hear the other party in the speaker, but the other party cannot hear you and the mute key is lit.

You have to press the mute key

 *to let the other party hear you.*

Voice Mail

Messages/Voice Mail

Call voice mail system (e.g. record greeting announcement): Press the **Services key**. **Select VoiceMail.**

Listen to received messages: *The message waiting lamp is slowly blinking and an envelope is displayed when there is a pending message.*

Press the **MessageWaiting** softkey.

Settings in the Telephone

SoftKeys

Do not program new softkey from the phone, because this programming can interfere with the keys used by the system. Use the Web User interface to program the softkeys:

Operation > Softkeys and XML

Normally you can program **bottom** keys with key number 9 and higher.

Normally you can program **top** keys with key number 5 or higher.

A softkey programmed by the user may be overwritten by the system if the administrator later sets a new key there.

The only type of softkey that a user normally shall program is speed dial keys with a phone number or a procedure.

Program a new softkey Use the web interface. See above

Settings in the Telephone

SoftKeys (Continued)

Create a Speed Dial key: Press and hold down a softkey, dial pad or expansion module key on the phone to initiate a speed dial feature.

Enter name, number and line.

Press **Save**

Or



> **Dialing> Speed Dial**

Edit >

Press the type of sofkey (e.g Top soft key)

Enter name, number and line.

Press **Save**

Note: Select a key that has no preassigned funtion .

Delete softkey: Use the Web interface to delete the softkeys:

Operation > Softkeys and XML

Volume

Adjust volume during a call: Press

Adjust ringing volume: Press when in idle mode.

Time and Date

Set time format: > **Time and Date**
>**Settings Time Format**

Set date format: > **Time and Date**
>**Settings> Date Format.**

Silent Ringing and Mute

Switch off ring signal: Press the left **Volume** key until the text **Ringer is OFF** is shown in the display.

Note: Ring signal is switched off until the right **Volume** key is pressed

Mute microphone during call:

Press 

Display Language

Change terminal language:  > **Language** > **Screen Language**

Select language

Press **Save**


Change system Language:

Enter ***08*n#** to inform the system about the language.

Press **Dial**

n = language number. Contact the system administrator.

Change keypad characters:

 > **Language** > **Input Language**.

Select language

Press **Save**

Directories (Contacts)

Corporate Directory

The system administrator will most likely have set **CorpDir** on a softkey.

Search for a contact:

Press the **CorpDir** softkey

In Corporate directory, you get prompted for "Name or Phone:" and Organization. If you want to search only by last name, enter e.g. the first letter of the last name.

If you want to search only by first name, enter a comma (press 1 seven times) followed by e.g. the first letter of the first name.

If you want to search by full name, enter e.g. the first letter of the last name and then the first letter of the first name separated by a space (press * twice).

Then press softkey **Search**. The search result is shown in the form of a list of names. Scroll in the list to the wanted contact.


Call from Corporate directory: Scroll in the search result list to the wanted contact and press softkey **Dial** to call.

Local Directory (Contacts)

- Add contact:** *Press the **Directory** softkey.*
- Press **Add New***
- Enter a name and number*
- Press **Save***
- Edit contact:** *Press the **Directory** softkey.*
- Select and highlight the wanted*
- Contact*
- Press **Edit** softkey*
- Edit desired information*
- Press **Save***
- Delete contact:** *Press the **Directory** softkey.*
- Select and highlight the wanted*
- Contact.*
- Press **Delete** softkey.*
- Press **Delete All** to delete all*
- contacts in the Local Directory.*

Web interface

Using the Web Interface

- Log On:** *Open a web browser on your PC.*
- Enter the IP address of the phone in*
- the address field in the web browser.*
- The log on window pops up*
- userid: user*
- password: blank is the default*
- password*
- Find out the**  **> Status > Network > IP &**
- phone IP address:** **MAC address.**
- Enter the IP address into the address*
- field in the web browser in your PC.*

FCC Statement (U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

HAC (Hearing Aid Compatible)

Subject to change without prior notice.
For questions regarding the product,
please contact your MitelCertified Sales Partner.
Also visit us on www.mitel.com

1424-EN_LZT 103 100 A

Printed on chlorine free paper.