



A MITEL  
PRODUCT  
GUIDE

# Mitel OpenScape Business

myPortal @work

User Guide

06/2026

## Notices

The information contained in this document is believed to be accurate in all respects but is not warranted by Mitel Europe Limited. The information is subject to change without notice and should not be construed in any way as a commitment by Mitel or any of its affiliates or subsidiaries. Mitel and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes. No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from Mitel Networks Corporation.

## Trademarks

The trademarks, service marks, logos, and graphics (collectively “Trademarks”) appearing on Mitel’s Internet sites or in its publications are registered and unregistered trademarks of Mitel Networks Corporation (MNC) or its subsidiaries (collectively “Mitel), Unify Software and Solutions GmbH & Co. KG or its affiliates (collectively “Unify”) or others. Use of the Trademarks is prohibited without the express consent from Mitel and/or Unify. Please contact our legal department at [iplegal@mitel.com](mailto:iplegal@mitel.com) for additional information. For a list of the worldwide Mitel and Unify registered trademarks, please refer to the website: <http://www.mitel.com/trademarks>.

© Copyright 2026, Mitel Networks Corporation

All rights reserved

# Contents

<b>1 History of changes.....</b>	<b>6</b>
1.1 History of improvements/fixes.....	6
<b>2 Introduction.....</b>	<b>8</b>
2.1 myPortal @work.....	8
<b>3 Installation.....</b>	<b>9</b>
3.1 How to Install myPortal @work (Windows).....	9
3.2 How to Uninstall myPortal @work (Windows).....	9
3.3 How to Install myPortal @work (Mac OS).....	9
3.4 How to Uninstall myPortal @work(Mac OS).....	10
<b>4 First Steps.....</b>	<b>11</b>
4.1 How to Start myPortal @work for First Time.....	11
4.2 How to Start myPortal @work.....	12
4.3 User Interface.....	13
4.4 How to Switch to the Mini View.....	15
4.5 How to Switch to the Details View.....	15
4.6 How to Switch to the List View.....	16
4.7 How to Switch to the Menu View.....	16
4.8 How to Close/Exit myPortal @work.....	16
<b>5 Unified Communications.....</b>	<b>18</b>
5.1 Directories.....	18
5.1.1 How to Search in Directories.....	19
5.1.2 How to Update a Personal Contact.....	20
5.1.3 How to Delete a Personal Contact.....	20
5.2 Presence Status.....	20
5.2.1 How to Change the Presence Status to Absent and Enable Status-based Call Forwarding.....	23
5.2.2 How to Change the Presence Status to Office.....	23
5.2.3 How to Change the Visibility of your Presence Status for Others.....	23
5.2.4 How to Configure the Pop-up Visibility for Active Calls.....	24
5.3 CallMe Service.....	24
5.3.1 How to Enable the CallMe Service.....	25
5.4 Favorites.....	25
5.4.1 How to Add a Contact to the Favorites.....	26
5.4.2 How to Delete a Contact from the Favorites.....	26
5.4.3 How to Rename a Group from the Favorites.....	26
5.4.4 How to Delete a Group from the Favorites.....	26
5.5 Conversations.....	27
5.5.1 How to Save a Conversation Entry as a Personal Contact.....	27
5.5.2 How to Display Details of a User in a Conversation Entry.....	27
5.5.3 How to Delete all Conversations.....	28
5.5.4 How to Delete a whole Conversation.....	28
5.5.5 How to Delete a Conversation Item (chat, journal, voicemail).....	28
5.5.6 How to Send an Instant Message from Conversations.....	28
5.5.7 How to Send an Instant Message from Favorites.....	29
5.6 Calls.....	29
5.6.1 Call Number Formats.....	30
5.6.2 Call Functions.....	30
5.6.2.1 How to Dial a Number using a Hotkey.....	32
5.6.2.2 How to Make a Call by Entering a Name.....	32

## Contents

5.6.2.3	How to Make a Call from Favorites.....	33
5.6.2.4	How to set a default phone number in Favorites.....	33
5.6.2.5	How to Make a Call from a Conversation Entry.....	33
5.6.2.6	How to Dial a Number Using the tel or callto Protocol.....	34
5.6.2.7	How to Redirect a Call to your Voicemail Box.....	34
5.6.2.8	How to Answer a Call.....	34
5.6.2.9	How to Redial a Call.....	35
5.6.2.10	How to Place a Call on Hold.....	35
5.6.2.11	How to Initiate a Consultation.....	35
5.6.2.12	How to Transfer a call after Consultation.....	35
5.6.2.13	How to Alternate between two Parties.....	36
5.6.2.14	How to Transfer a Call.....	36
5.6.2.15	How to Pick up a Call from the Favorites List.....	36
5.6.2.16	How to Initiate a Conference During a Call.....	36
5.6.2.17	How to End a Call.....	37
5.6.2.18	How to Dial a Number Manually.....	37
5.6.2.19	How to use DTMF tones during an active VoIP call.....	37
5.7	Voicemail.....	38
5.7.1	How to Listen to a Voice Message on the Phone.....	39
5.7.2	How to Activate or Deactivate Message Recording.....	39
5.7.3	How to Change your PIN for the Voicemail Box.....	39
5.7.4	Notification Service for Messages.....	40
5.8	Conferences.....	40
5.8.1	How to Create a Conference.....	42
5.8.2	How to Display a Conference.....	43
5.8.3	How to Rename a Scheduled Conference.....	44
5.8.4	How to Dial into a Conference.....	44
5.8.5	How to Add Conference Participants.....	44
5.8.6	How to Disconnect a Conference Participant.....	45
5.8.7	How to Remove Conference Participants.....	45
5.8.8	How to Delete a Scheduled Conference.....	45
<b>6</b>	<b>Configuration.....</b>	<b>47</b>
6.1	Personal Preferences.....	47
6.1.1	How to Edit your Contact Data.....	47
6.1.2	How to Provide your own Image.....	47
6.1.3	How to Delete your own Picture.....	48
6.2	Dialing Hotkey Settings.....	48
6.2.1	How to Define a Hotkey for Speed Dialing.....	48
6.3	Programming the Function Keys of the Telephone.....	49
6.3.1	How to Program the Function Keys of the Telephone.....	49
6.4	General Settings.....	50
6.4.1	How to Change your myPortal @work Password.....	50
6.4.2	How to Enable or Disable the Automatic Login of myPortal @work.....	51
6.4.3	How to Select the User Interface Language.....	51
6.4.4	How to Select the Date Format.....	51
6.4.5	How to Configure the Pop-up Visibility for Active Calls.....	52
6.4.6	How to Add a Personal Contact.....	52
6.4.7	How to Import Contacts into the Personal Contacts.....	52
6.4.8	How to Edit the Server Settings.....	53
6.4.9	How to Configure Additional Server Connections.....	53
6.4.10	How to Enter the Call Number for the Associated Phone (for a MULAP).....	54
6.4.11	VoIP in myPortal @work.....	54
6.4.11.1	How to Enable VoIP.....	55
6.4.11.2	How to Enable Simplified SDP Negotiation.....	56
6.4.11.3	How to Manage Audio settings.....	56

6.4.11.4 How to Check NAT type..... 57  
6.4.11.5 How to Add a STUN server..... 57  
6.4.12 How to Configure the Headset Integration..... 58  
6.4.13 How to Change the Dialing Mode (only for Mobility Users)..... 59  
6.4.14 How to Reconnect with myPortal @work..... 59

**Index..... 60**

# 1 History of changes

Changes mentioned in the following list are cumulative.

## Changes in V3R1

Impacted chapters	Change description
-	Initial creation of the document

## 1.1 History of improvements/fixes

Changes mentioned in this chapter are cumulative.

### Changes in V3R2 FR1

Service case ID	Date of change	Description of change	Impacted chapters
PRB000064905	14 Feb. 2023	Corrected standard PIN number.	<a href="#">How to Change your PIN for the Voicemail Box</a> on page 39
PRB000067006	11 May 2023	The service is only available in UC Suite mode.	<a href="#">CallMe Service</a> on page 24

### Changes in V3R2

Service case ID	Date of change	Description of change	Impacted chapters
PRB000063604	07 Dec. 2022	Added info about the number of contacts that are supported in UC Smart mode.	<a href="#">How to Add a Personal Contact</a> on page 52

### Changes in V3R1 FR2

Service case ID	Date of change	Description of change	Impacted chapters
PRB000055393	12 Jan. 2022	Added info about transferring call	<a href="#">How to Transfer a call after Consultation</a> on page 35
PRB000054954	14 Feb. 2022	Added note for conversation entries.	<a href="#">Call Number Formats</a> on page 30

### Changes in V3R1 FR1

Service case ID	Date of change	Description of change	Impacted chapters
PRB000054934	12 Nov. 2021	Added info about the number of conversations that are displayed in the client.	<a href="#">Conversations</a> on page 27

### Changes in V3R1

Service case ID	Date of change	Description of change	Impacted chapters
PRB000051895	23 Mar. 2021	Added note for favorite contacts	<a href="#">Favorites</a> on page 25
PRB000052523	09 Apr 2021	Added note for hold call function	<a href="#">Call Functions</a> on page 30

Service case ID	Date of change	Description of change	Impacted chapters
PRB000051643	16 Jun 2021	Fixed error	<a href="#">Call Number Formats</a> on page 30

## 2 Introduction

This document is intended for the users of myPortal@work and describes its installation, operation and configuration.

### 2.1 myPortal @work

myPortal@work is a Unified Communication Application, which combines all needed features and services, like convenient dialing via phone directories, favorites, conversations and information on the presence status of colleagues, into a single solution design to accelerate daily communication, improve teamwork and to get in quick contact with colleagues, customers and Partners.

myPortal @work can be used either in UC Smart or in UC Suite mode. Depending on the mode, the offered features in the user interface vary. You cannot change the operation mode, as this is set by the system configuration. In case of any doubt about the current operation mode of your myPortal @work client, ask your system administrator for details.

myPortal @work offers an embedded Voice over IP (VoIP) telephony client. If the VoIP option is activated, the voice call related features of the myPortal @work client use the VoIP functionality.

myPortal @work in UC Smart mode can be used instead of an existing myPortal Smart client. Existing UC Smart settings are automatically incorporated into myPortal @work after its installation. The existing UC Smart user licenses can also be used with myPortal @work.

myPortal @work in UC Suite Mode can be used not only as stand-alone but also in combination with existing myPortal for Desktop/Outlook Client (CTI, Favorites and Conversations). The existing UC Suite user licenses can also be used with myPortal @work.

The following description refers mainly to my Portal @work in UC Smart mode. Deviations for the UC Suite mode are pointed out explicitly.

myPortal @work supports generally the following features:

- Presence status
- Status-based call forwarding
- Directories including search by name
- Favorites
- Conversations
- Instant messaging
- Conferencing
- Hotkey Dialing / Hotkey Search
- Call Functions either via:
  - 1) Associated telephone device
  - 2) Integrated Voice over IP telephony client
- Voicemail control
- Zoom In / Zoom Out

## 3 Installation

It is recommended that the myPortal @work client software is installed by your system administrator. You can also install the software by yourself if your system administrator has prepared the communication system accordingly and has provided the following prerequisites to you:

- Administrator rights
- myPortal @work software setup program
- IP addresses and ports of the communication system
- Login Data (User and Password) for your UC user account in the communication system
- Voice-Mail account information (optional)
- MULAP call number in case of multiple number assignment (optional)

---

**NOTICE:** Make sure that TLS1.2 protocol support is enabled within the Windows operating system for a secure data transmission by myPortal @work.

---

### 3.1 How to Install myPortal @work (Windows)

#### Prerequisites

The administrator of your communication system has made the myPortal @work installation file available to you.

#### Step by Step

- 1) Run the installation file `myPortalAtWorkSetup.exe`.
- 2) Click on **Install** and follow the instructions of the installation program.

---

**NOTICE:** You do not need to have local administrator rights to install or update myPortal @work client.

---

### 3.2 How to Uninstall myPortal @work (Windows)

#### Step by Step

- 1) Close myPortal @work.
- 2) Click in the **Control Panel > Programs and Features**.
- 3) Click on **Uninstall** in the context menu of **myPortal @work**.

### 3.3 How to Install myPortal @work (Mac OS)

#### Prerequisites

The administrator of your communication system has made the myPortal @work installation file available to you.

## Installation

How to Uninstall myPortal @work(Mac OS)

### Step by Step

- 1) Run the .dmg installation file
- 2) Click on **Install** and follow the instructions of the installation program.

---

**NOTICE:** You do not need to have local administrator rights to install or update myPortal @work client.

---

## 3.4 How to Uninstall myPortal @work(Mac OS)

### Step by Step

- 1) Close myPortal @work.
- 2) Click in **Finder** on **Applications**.
- 3) Drag **myPortal @work** to the **Recycle Bin**.
- 4) If all the settings for myPortal @work are to be deleted as well, delete the **Client** folder in the user directory.

## 4 First Steps

The First Steps describe the user interface and the recommended actions to be taken right at the beginning.

### 4.1 How to Start myPortal @work for First Time

#### Prerequisites

myPortal @work is installed to your PC.


The administrator of your communication system has enabled the UC Smart or UC Suite solutions and configured an initial password for the use of myPortal @work.

You have received the **User name** (phone number), **Password** (initial password), **Server IP address** either for LAN or WAN access and the **Port Number** from your administrator.

#### Step by Step

- 1) To start myPortal @work, click on **Start > myPortal @work**.
- 2) Click on one of the four buttons to enter your configuration data.

You can configure up to four different server connections in the login screen.



---

**NOTICE:** In case of MULAP or Mobility Users, the configuration is done only in **User account** tab, see [How to Configure Additional Server Connections](#)

---

- 3) Enter your internal phone number (e.g., 330) in the **User Name** field.
- 4) Enter the initial password for myPortal @work that you received from your administrator in the **Password** field.
- 5) Enter the WAN server address data (required for WAN access via the Internet to the UC Server):
  - In **IP WAN server address:Port** field enter the IP address or name of the UC Server together with the port number that you received by the

## First Steps

### How to Start myPortal @work

administrator. Enter the IP address and port number in one line separated by a colon (:).

---

**IMPORTANT:** The Online Help documentation is served via the HTTPS port (443) of the communication system. If you are logging in via a public IP address (WAN) where only the application port (e.g., 8802) is forwarded, the Online Help will not be accessible.

To access the Online Help from a remote location, it is recommended to connect to the communication system via a VPN connection (using the system's LAN IP).

---

- 6) Enter the LAN server address data (required for internal access to the UC Server):
  - In **IP LAN server address:Port** field enter the IP address or name of the UC Server together with the port number that you received by the administrator. Enter the IP address and port number in one line separated by a colon (:).
- 7) Click on **Login**.
- 8) A pop-up window appears in order to install the certificate. Click **YES** to accept the certificate.
- 9) If this is the first time you start myPortal @work, you are prompted by the myPortal @work client to change your login password depending on the administrator configuration:
  - UC Smart mode, see [How to Change your myPortal @work Password](#)
  - UC Suite mode (use another UC Suite client).

---

**NOTICE:** The default password is set by the administrator.

---

---

**NOTICE:** If myPortal @work displays the message "Connection Time out", the UC Server cannot be reached. In this case please check the IP address and port information in your myPortal@ work login settings. In addition, check the network and proxy settings of your PC. In case of any doubt contact your network or system administrator.

---

## 4.2 How to Start myPortal @work

### Prerequisites

You have already replaced the initial password with your own password when you started myPortal @work for the first time.

### Step by Step


Select one of the following options on **Start > myPortal @work**

## 4.3 User Interface

The user interface can be represented in three different views: Details View (A), List View (B), Menu View (C) and Mini View (D). Your own presence status, as well as information about missed calls and new voice messages are visible in every view.

The views are generated dynamically depending on the UC Smart, UC Suite mode and the configuration of features in your communication system.

The following figures present myPortal @work in UC Suite mode with limited feature set.



1	Application header
2	Name
3	<b>VoIP Settings</b> button
4	<b>Dock</b> button
5	<b>Set on top</b> button
6	<b>Minimize</b> button

7	<b>Close button</b>
8	<b>Presence status - with your current status</b>
9	<b>Favorites</b>
10	<b>Conversations</b> Displays all events per contact
-	<b>Conference</b> (UC Smart mode only)
11	<b>Search/ Dial</b> field - with the following functions: <ul style="list-style-type: none"> <li>• Input field for phone number to be dialed</li> <li>• Input field for name to be searched</li> <li>• Dropdown list with 10 last dialed numbers for quick redial</li> </ul>
12	<b>Minimize bar</b> button

**No connection to the system**

If myPortal @work has lost the connection to the communication system, the current screen will be greyed out and an information text is displayed. In this case you can still reach the menu to exit the application or change the connection settings.

**Screen Pops**

For calls, the appropriate call information and buttons are displayed in screen pops or in the workspace of the conversations, if that view is currently active.

**Tooltips**

Tooltips are tiny windows in which myPortal @work displays more information on objects of the graphical user interface such as icons, input fields or buttons, for example. The appropriate tool tip appears when you let the mouse pointer hover over that element for a brief period of time.

**Notifications**

myPortal @work has the following notifications. When the conversations are selected, the notifications are marked as read.

- The number of conversations can be seen in the conversations menu.
- A notification bubble showing the number of conversation entries, in docked mode.

- A visual notification without any specific indications, in the system tray.



## Conversations menu

### 4.4 How to Switch to the Mini View

#### Step by Step

Select one of the following options:

- If you are in the Details view:
  - Click on the **Dock** button to move to other screen.
  - Click the **Pin window** button.
  - Move your mouse out of myPortal @work screen.
- If you are in the List view:
  - Click on the **Dock** button to move to other screen.
  - Click the **Pin window** button.
  - Move your mouse out of myPortal @work screen.
- If you are in the Menu view and you have firstly followed the steps from Details or List view:
  - Move your mouse out of myPortal @work screen.

### 4.5 How to Switch to the Details View

#### Step by Step

Select one of the following options:

## First Steps

### How to Switch to the List View

- If you are in the Menu view:  
Double-click on any menu icon of the menu bar.
- If you are in the List view:  
Click on the already selected menu icon of the menu bar.
- If you are in the Mini view:  
Open the application by hovering Mini view and follow the above steps in case you are in the Menu or List view.

## 4.6 How to Switch to the List View

### Step by Step

Select one of the following options:

- If you are in the Menu view:  
Click on any menu icon of the menu bar.
- If you are in the Details view:  
Click on the **Minimize bar** or on the already selected menu icon of the menu bar.
- If you are in the Mini view:  
Open the application by hovering Mini view and follow the above steps in case you are in the Menu or Details view.

## 4.7 How to Switch to the Menu View

### Step by Step

Select one of the following options:

- If you are in the Details view:  
Click twice on the **Minimize bar**.
- If you are in the List view:  
Click on the **Minimize bar**.
- If you are in the Mini view:  
Open the application by hovering Mini view and follow the above steps in case you are in the Details or List view.

## 4.8 How to Close/Exit myPortal @work

### Prerequisites

You are in the Details or List view.

### Step by Step

- 1) To close the application window, click on the **Close** button in the application header. The application will continue to run in the system tray.
- 2) To close and remove the application from the system tray, click on your name and then click on **Exit**.

- 3) To logout from the application, click on your name and then **Logout**. By selecting this option, you will have to enter again your credentials to login.

## 5 Unified Communications

Unified Communications is a generic term that refers to the integration of different communication systems, media, devices and applications within an environment (e.g., telephony, presence, voicemail and instant messaging).

### 5.1 Directories

Directories contain your contacts. myPortal @work provides access to the following directories:

- **Personal contacts directory**  
Contains your personal contacts.
- **Internal directory**  
Contains the internal UC subscribers.
- **System directory** (speed dials)  
Contains all speed-dial destinations of the communication system.
- **Global directory**  
Contains contacts which are imported by the administrator into the communication system.
- **External directory (UC Suite only)**  
Contains the contacts from the external directory of the UC Suite.

The contents of the directories can be accessed via the Search/Dial field of myPortal @work. You can search the directories by name and dial contacts directly or add contacts to your Favorites.

In UC Smart mode you can manage the content of your personal contacts with myPortal @work either manually one by one or via bulk import from XML/CSV file or from Microsoft Outlook contacts. You can also add contacts from the journal or senders of voicemails. Imported contacts can be edited in myPortal @work. Such contacts are marked as "manually added contacts" and are no longer synchronized during the next import (Outlook, CSV or XML).

In UC Suite mode you need to add or import your personal contacts using another UC Suite client.

The content of all other directories are managed by your system administrator. The personal contacts are stored by the UC Application in OpenScape Business and are not shared to any other UC users.

---

**NOTICE:** Phone numbers in directories should always be entered in canonical format (e.g., +4989700798765).

---






#### Contact Details

The Details view of contacts shows the following details in the search results:

- Picture (if present)
- Name
- Presence status (only for internal subscribers), possibly with the scheduled time of return and info text

- Phone numbers and email address (if available)

Clicking on a contact or a hit in the quick search shows the following details:

Symbol	Meaning
	Internal call number
	Business phone number
	Private or external phone number
	Mobile phone number
	Email address

Only the name and number are available in the system directory.

### Search

You can search directories by name or by the initial letters of a name. If a contact that matches the specified name is found, the details for that contact are displayed.

Wildcard character "\*" is supported at the end of a search string. German diacritics are supported.

---

### Related concepts

[Presence Status](#) on page 20

## 5.1.1 How to Search in Directories

### Step by Step

- 1) Enter the first letter of the desired name in the **Search/Dial** field.
- 2) All entries from the directories starting with the letters you have entered will be displayed in a list.
- 3) You can select a specific directory by clicking on the **Search results** and activating an option from the drop down menu.
- 4) Click on a contact to see more details.

---

### Related tasks


[How to Add a Contact to the Favorites](#) on page 26

## 5.1.2 How to Update a Personal Contact

### Prerequisites

UC Smart mode

### Step by Step


- 1) Click on the **Search/ Dial** field and type the name of contact you are searching for.
- 2) Click on the personal contact you want to update.
- 3) Click on .
- 4) Click on **Update personal contact** button in the Details tab of the contact.
- 5) Update the contact data in the **Update Personal Contact** window.
- 6) Click on **OK**.

## 5.1.3 How to Delete a Personal Contact

### Prerequisites

UC Smart mode

### Step by Step

- 1) Click on **Search/ Dial field** and type the name you are searching for.
- 2) Click on the personal contact you want to delete.
- 3) Click on .
- 4) Click on **Delete personal contact** button.
- 5) Click on **OK**.










## 5.2 Presence Status

The Presence status indicates the availability of internal subscribers and mobile users in Favorites, the internal directory and in voicemail announcements.






You can change your presence status in myPortal @work, in the phone menu of the voicemail box (Voicemail), with myPortal for OpenStage and in other UC clients. For every change in the presence status (except for **Office**), you also define the scheduled date and time of your return to the **Office** status. In addition, you can define the destination to which the calls are to be forwarded.

The following symbols are available for the presence status:

Symbol	Presence status	Availability
	<b>Office</b>	Available - optional: status-based call forwarding (e.g., for home office)

Symbol	Presence status	Availability
	<b>CallMe</b> Only selectable if the CallMe service is active Otherwise, <b>Office</b> appears here.	Available at an alternative workplace, only in UC Suite mode.
	<b>Sick</b>	Absent – optional: status-based call forwarding
	<b>Break</b>	Absent – optional: status-based call forwarding
	<b>Gone Out</b>	Absent – optional: status-based call forwarding
	<b>Vacation</b>	Absent – optional: status-based call forwarding
	<b>Lunch</b>	Absent – optional: status-based call forwarding
	<b>At Home</b>	Absent – optional: status-based call forwarding
	<b>Do Not Disturb</b>	Absent (not available in MULAP configurations)
		Presence status is not visible

The following additional symbols for the connection status appear in the Favorites and in the internal directory for subscribers:

Symbol	Connection status
	Subscriber receives an internal call
	Subscriber receives an external call
	Subscriber is calling
	The subscriber is on the phone (internal)
	The subscriber is on the phone (external)

### Status-Based Call Forwarding

UC Smart mode:

Status-based call forwarding enables you to forward calls to your voicemail box or a special phone number based on your presence status, for example, to your mobile phone if you are out of the office or to your delegated representative during your vacation.

You can configure status-based call forwarding for every presence status except **Do Not Disturb**. In this case, the communication system redirects your incoming calls to the configured forwarding destination (by default, your voicemail box) and notifies the callers via status-based announcements about the nature of your absence and possibly the scheduled date and time of your return.

If you do not have a personal voicemail box, you can also forward the calls to a group mailbox or a system mailbox. myPortal @work does not provide direct access to group mailboxes. You can, however, have these voicemails delivered to you via the **Voicemail to email** feature (see [Notification Service for Messages](#) on page 40).

For each presence status, the type or number of the forwarding destination is displayed under **my presence**.

UC Suite mode:

If your Presence status is not Office or CallMe, the communication system redirects your incoming calls to the configured forwarding destination (by default, your voicemail box) and notifies the callers via status-based announcements about the nature of your absence and the scheduled time for your return.

---

**NOTICE:** The configuration for forwarding destination is done by another UC Suite client.

---

### Visibility of your Presence Status

You can specify, within the setting, who is to be notified about your presence status other than **Office** (as well as the scheduled time of your return and any info text you have entered) via a display in the UC Smart client or via automatic voicemail announcements:

- **internally and externally**  
Visible to both internal subscribers (display in UC Smart client and voicemail announcements) as well as external callers (voicemail announcements)
- **internally**  
Visible only to internal subscribers (display in UC Smart client and voicemail announcements)
- **not visible**  
Not visible to all others

After the scheduled time for your return has passed, the announcement of this time is dropped. Your presence status remains unchanged.

---

### Related concepts

[Directories](#) on page 18

[Favorites](#) on page 25

## 5.2.1 How to Change the Presence Status to Absent and Enable Status-based Call Forwarding

### Step by Step

- 1) Click on the **Presence status**.
- 2) Click on one of the following Presence status: **Meeting, Sick, Break, Gone Out, Vacation, Lunch, At home** or **Do not disturb**.
- 3) If you want to enable status-based call forwarding to a predetermined destination, select the appropriate entry in the **Calls will be forwarded to** drop-down list (**Voicemail, Mobile** or **External**).
- 4) If you want to specify the time of your return, click on the calendar icon and select the date and time accordingly.
- 5) If you want to specify an info text for the Presence status, enter it in the Note field.
- 6) Click on **Apply**.

## 5.2.2 How to Change the Presence Status to Office

### Step by Step

- 1) Click on the **Presence status**.
- 2) Click on **Office**.
- 3) If you want to specify an info text for the Presence status, enter it in the text field.
- 4) Click on **Apply**.

## 5.2.3 How to Change the Visibility of your Presence Status for Others

### Step by Step

- 1) Click on your name.
- 2) Click on **Settings > Appearance**.
- 3) Select one of the following options in the **Presence visibility** drop-down list:
  - If you want to make your presence status visible to both internal subscribers as well as external callers, click on **internally and externally**.
  - If you want to make your presence status visible to internal subscribers only, click on **internally**.
  - If you want to make your presence status invisible to all subscribers, click on **not visible**.

## 5.2.4 How to Configure the Pop-up Visibility for Active Calls

### Step by Step

- 1) Click on your user name.
- 2) Click on **Settings > Appearance**.
- 3) Select one of the following options in the **Popup visibility** drop-down list:

Option	Description
<b>Always visible</b>	The pop-up window always appears
<b>5 seconds</b>	The pop-up window appears for 5 seconds
<b>10 seconds</b>	The pop-up window appears for 10 seconds
<b>When minimized</b>	The pop-up window appears only when minimized or when pin window is disabled
<b>Never visible</b>	The pop-up window never appears

## 5.3 CallMe Service

The CallMe service (available only in UC Suite mode) can be used to define any phone at an alternative workplace as the CallMe destination at which you can be reached through your own internal phone number. You can use the UC client at your alternative workplace exactly as in the office and thus also make outgoing calls from the CallMe destination.

### Inbound Calls

Calls to your internal number are redirected to the CallMe destination. Your internal phone number is displayed to the caller. Unanswered calls are forwarded to the voicemail box after 60 seconds.

### Outbound Calls

When you dial a number in the UC client, the communication system first calls you at the CallMe destination. If you answer the call, the communication system then calls the desired destination and connects you with it. Your internal phone number is displayed at the destination (One Number Service).

### Presence Status

When the CallMe service is enabled, the message "CallMe active" appears in the display of your phone (not for analog and DECT phones). Other subscribers will see your presence status as **Office**.

### Activation

You can activate the CallMe service manually. In addition, the CallMe service is also reactivated by an automatic reset of the Presence status following an absence, provided it was active earlier. Then following types of CallMe destinations are not supported:

- Group

- Redirected telephone

---

**NOTICE:** When the CallMe service is enabled the call handling happens on the background without a popup notification during the call.

---

#### Deactivation

The CallMe service remains active until you delete the **CallMe number**.

---

**NOTICE:** CallMe function should not be used when dialing or calling in an open conference.

---

### 5.3.1 How to Enable the CallMe Service

#### Step by Step

- 1) Select **Office** for the Presence status.
- 2) Set the call number of the CallMe destination.

---

**NOTICE:** Do not enter a group or a redirected phone as the CallMe destination.

---

- 3) Click **Apply**.

### 5.4 Favorites

The Favorites shows you all the contacts you have configured as favorites at a glance. These contacts can also be called very easily directly from the Favorites.

The Favorites manages contacts in groups.

All internal subscribers that were copied over from the internal directory into the Favorites can be seen with their respective presence status and connection status.

When an internal subscriber receives a call, this is indicated to you in the presence status of the subscriber. You can then take this call.

---

**NOTICE:** myPortal @work Favorites do not include personal contacts imported from Outlook.

---

---

**NOTICE:** If you answer the call of another subscriber, this call will be indicated as missed to the original subscriber. "Answered by" information is not provided.

---

There are differences in the handling of Favorites between UC Smart and UC Suite mode.

---

**Related concepts**

[Presence Status](#) on page 20

## 5.4.1 How to Add a Contact to the Favorites

### Step by Step

- 1) Enter the name of the contact in the **Search/Dial** field.
- 2) Click on the contact you want to add to the Favorites.
- 3) In the details view of the contact, click on the star button.
- 4) Select one of the following options for the group to which the contact is to be added:
  - Select an existing group in the drop-down list.
  - Create new favorites group by entering a name in the input field, and then click on Add.


---

**Related tasks**

[How to Search in Directories](#) on page 19

## 5.4.2 How to Delete a Contact from the Favorites

### Step by Step

- 1) Click on the **Favorites** icon in the main menu.
- 2) Click on the relevant group to expand the associated Favorites entries.
- 3) Click on the relevant contact.
- 4) Click on .
- 5) Click on **Delete from <name of the group>**.

## 5.4.3 How to Rename a Group from the Favorites

### Step by Step

- 1) Click on the **Favorites** icon in the main menu.
- 2) Click on the relevant group and then click on the **Rename group** button.
- 3) In the pop-up window, change the name of the Favorites group.
- 4) Click on **OK**.

## 5.4.4 How to Delete a Group from the Favorites

### Step by Step

- 1) Click on the **Favorites**.
- 2) Click on the relevant group to expand the associated Favorites entries.
- 3) Click on the **Delete group** button.
- 4) Click on **OK**.

---

**NOTICE:** This feature is only available with the UC Smart solution. In the UC Suite mode, favorite groups can be deleted with another UC Suite client.

---

## 5.5 Conversations

**Conversations** contain the history of your activity.


The conversation entries are displayed per contact and each entry contains details about the following events:

- Calls
- Voicemails
- Instant Messaging (UC Smart mode)

MyPortal @work displays up to 25 conversations and each conversation has up to 50 entries.

The latest event is always displayed first on an entry. The active and on hold calls are displayed on top on the List view. If you have unread events a green counter is shown in the entry, which indicates the number of the unread events.

Each Conversation entry contains the following in the details view:

- The history of the events, showing always the latest events at the end of the view.
- Information about the conversation entry by clicking on .

---

**NOTICE:** Call control is handled by Conversations list.


---

### 5.5.1 How to Save a Conversation Entry as a Personal Contact

#### Prerequisites

UC Smart mode

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Click on the desired conversation entry.
- 3) Click on  and then click on **Add to Personal Contacts**.
- 4) Complete the data as needed in the **Add Personal Contact** pop-up window and click **OK**. The contact is saved in the personal contacts.

### 5.5.2 How to Display Details of a User in a Conversation Entry

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Click on the desired conversation entry.

- 3) Click on .

### 5.5.3 How to Delete all Conversations

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Click the down arrow next to **Conversations** button.
- 3) Click on **Delete all conversations**.
- 4) Click on **OK**.

All conversations that you delete in myPortal @work are also immediately deleted from myPortal for Desktop, myPortal for Outlook and myAttendant (live updated) if you are logged in with the same account.

### 5.5.4 How to Delete a whole Conversation

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Click on the desired conversation entry.
- 3) Click on **Details** and then click on **Delete this conversation**.
- 4) Click on **OK**.

The whole conversation that you delete in myPortal @work is also immediately deleted from myPortal for Desktop, myPortal for Outlook and myAttendant (live updated) if you are logged in with the same account.

### 5.5.5 How to Delete a Conversation Item (chat, journal, voicemail)

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Click on the desired conversation entry.
- 3) Click on **Click for more actions**.
- 4) Click on **Delete this entry**.
- 5) Click on **OK**.

A journal entry that you delete in myPortal @work is also immediately deleted from myPortal for Desktop, myPortal for Outlook and myAttendant (live updated) if you are logged in with the same account.

### 5.5.6 How to Send an Instant Message from Conversations

#### Prerequisites

Instant Messaging is enabled in the system.

Selected contact is able to receive instant messages

UC Smart mode

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Click on the desired contact.
- 3) Click on a folder to expand the corresponding entries of the search results.
- 4) Enter your message in the respective field on the details view.
- 5) Click on **Send**.

## 5.5.7 How to Send an Instant Message from Favorites

#### Prerequisites

UC Smart mode

#### Step by Step







- 1) Click on the **Favorites** icon in the main menu.
- 2) Click on the relevant group to expand the associated Favorites entries.
- 3) Click on the desired contact.
- 4) Enter your message in the respective field on the details view.
- 5) Click on **Send**.




## 5.6 Calls

The call history of all your inbound and outbound calls is displayed in the **Conversation** icon in the main menu.

#### Identification of Call History

The call events in a conversation entry are identified as follows:

Symbol	Folder
	Inbound call - Answered
	Inbound call - No answer
	Inbound call to a group - Answered
	Inbound call to a group - not accepted
	Inbound call, forwarded or transferred
	Outbound call - Answered

Symbol	Folder
	Outgoing call - No answer
	Outgoing call to a group - Answered
	Outgoing call to a group - No answer

### 5.6.1 Call Number Formats

Call numbers can be specified in different formats.

Format	Description	Example
Canonical	Begins with + and always includes the country code, area code and the full remaining station number. Blanks and the special characters + ( ) / - : ; are allowed.	+49 (89) 7007-98765
Dialable	In order to dial from the client, use the format provided in the example column.	<ul style="list-style-type: none"> <li>• 321 (internal)</li> <li>• 700798765 (own local network)</li> <li>• 089700798765 (external local network)</li> <li>• 004989700798765 (international)</li> </ul>

---

**INFO:** If possible, you should always use the canonical call number format. This ensures that a phone number is always complete, unique and consistent for networking and mobile stations in every situation.

---



---

**NOTICE:** If the same number is dialed with different formats, then these calls will be shown in different conversation entries.

---



---

**NOTICE:** For calls within the USA to a number in canonical format, phone numbers are converted to the dialable format.

---











### 5.6.2 Call Functions

MyPortal @work can either control an associated phone or make use of the embedded VoIP telephony client. Depending on the chosen configuration within myPortal @work and the communication system, the call control function can be slightly different.

### Call Functions

Using the call functions of myPortal @work, you can access the features of your communication system. The available function buttons offered, are call status dependent.

Information and possibly a picture of the caller are displayed together with some of the following buttons, depending on the situation:

Symbol	Description
	<b>Accept Call</b>
	<b>Disconnect</b>
	<b>Consultation/ Alternate</b>
	<b>Retrieve call</b>
	<b>DTMF (only for VoIP functionality)</b>
	<b>Deflect to Voicemail (during an incoming call)</b>
	<b>Blind transfer / Deflect to phone</b>
	<b>Conference (phone-controlled)</b>
	<b>Hold Call (not for VoIP functionality)</b>
	<b>Mute (only for VoIP functionality)</b>

Calls can be initiated either by entering the phone number manually into the Search/Dial field or by clicking to an entry in the Conversations List, the Favorites List or a directory.

A phone number selected in a different application can be automatically transferred to myPortal @work and dialed by using a hotkey. To do this, a hotkey must be configured under the myPortal @work setting.


### Pop-up windows

Pop-up windows offer a convenient way to respond to calls with a single click. For example, in case of an incoming call, a pop-up window appears in the lower right corner of the screen displaying phone number and if available name and image of the caller. The same call buttons that appear in the screen pops are also displayed in the main application.


#### User Interaction and Call Management Scenarios

- Users can answer calls via a single call pop-up, while call options such as blind transfer, consultation, release or deflect calls appear.


- When the user has multiple calls, the pop-up displays the number of active calls. These calls can be managed via the list view, depending on the call state (established calls, ringing calls).
- Users can handle multiple calls, with a scroll bar appearing in the list view. The status of the users as a MULAP or simple group members, does not affect pop-up information.
- Scheduled and ad-hoc conferences are mentioned but not in detail. Also, users can call voicemail while managing other incoming calls.
- Calls from unknown or known external callers are identified in the pop-up.




single call pop-up



calls list view, calls appear top-down in the order they arrive



multiple calls pop-up



call management in the calls list view

### 5.6.2.1 How to Dial a Number using a Hotkey

#### Prerequisites

A hotkey was configured for this feature under settings.

#### Step by Step

- 1) Mark the number to be dialed in your application.
- 2) Press the key combination (hotkey) configured for the speed dial.

The phone number is displayed in the active call area of myPortal @work. The dialing is automatically performed.

### 5.6.2.2 How to Make a Call by Entering a Name

#### Step by Step

- 1) Enter the initial letters of the name of the subscriber to be called in the **Search / Dial** field. All entries from the directories containing the letters you have entered will be displayed in a list.

- 2) Click on the desired entry and then select one of the following options:
  - a) Click on the dial shortcut button for the first available phone number
  - b) Click on the ▼ to select a desired phone number and then click on the phone number to start the call.

### 5.6.2.3 How to Make a Call from Favorites

#### Step by Step

- 1) Click on the **Favorites** icon in the main menu.
- 2) Click on the relevant group to expand the associated favorites entries.
- 3) Select one of the following options:
  - a) Click on the call button on the entry in the Favorites. The contact will be called on the first stored phone number.
  - b) Click on the desired entry in the Favorites. Click on ▼ and then click on the desired phone number.

Once you initiate the call, a conversation entry is created automatically in the Conversations.

### 5.6.2.4 How to set a default phone number in Favorites

#### Prerequisites

UC Smart mode

#### Step by Step

- 1) Click on the **Favorites** icon in the main menu.
- 2) Click on the favorite contact you want to set the default number.
- 3) Click on ▼
- 4) Set as default your desired phone number by clicking on it. The icon is changed automatically next to the contact.

---


**NOTICE:** The call button is automatically updated next to the contact.

---

### 5.6.2.5 How to Make a Call from a Conversation Entry

#### Step by Step

- 1) Click on the **Conversations** icon in the main menu.
- 2) Locate the desired conversation entry.

- 3) Select one of the following options:
  - a) Click on the call button in the details view. The contact will be called back at the displayed number.
  - b) Click on the desired entry. Click on the  and then click on the desired phone number.
  - c) Click on the call button directly in the conversation entry.

### 5.6.2.6 How to Dial a Number Using the tel or callto Protocol

With myPortal @work you can make outgoing calls from a web browser by clicking on hyperlinks which are intended for telephony usage.

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Appearance** tab.
- 4) Enable **Always use this application for Telephony Hyperlinks**.

---

**NOTICE:** When you enable **Always use this application for Telephony Hyperlinks** myPortal @work is set as the default application. If you disable this option, myPortal @work continues to be the default application, until it is changed by a user or another application.

---

- 5) Click on the Uniform Resource Identifier (**URI**).

---

**NOTICE:** For Windows 10 only callto Protocol is supported.

---

### 5.6.2.7 How to Redirect a Call to your Voicemail Box

#### Prerequisites

Screen pops for inbound calls have been activated.

#### Step by Step

Click in the **Inbound Call** screen pop on the **Forward** symbol.

### 5.6.2.8 How to Answer a Call

#### Step by Step

Click in the **Inbound Call** screen pop on the **Answer** symbol.

---

**NOTICE:** In the case of an analog or DECT phone, you must lift the handset.

---

### 5.6.2.9 How to Redial a Call

#### Step by Step

- 1) In the **Search/Dial** field click on the arrow on the right.

---

**NOTICE:** A drop-down list with 10 last dialed numbers appears.

---

- 2) Click on the desired contact.

### 5.6.2.10 How to Place a Call on Hold

#### Prerequisites

Screen pops for inbound and outbound calls have been activated.

#### Step by Step

- 1) Click on the **Hold** symbol.
- 2) When you want to resume (unhold) the call, click on the **Reconnect** symbol.

### 5.6.2.11 How to Initiate a Consultation

During a call, you can initiate a consultation call with another subscriber.

#### Step by Step

- 1) Click on the **Consultation to another party** button on an active call.
- 2) Enter the phone number in **Search/Dial** field and press Enter.

### 5.6.2.12 How to Transfer a call after Consultation

#### Step by Step

- 1) After the Consultation you have to select from the Conversation list the call that you want to transfer.
- 2) Click on the **Attended Transfer** option from the call on hold to transfer the call.

When you are connected to the Consultation user you have to select the original call, which is on hold after the consultation. You have to select again the original call to view the Attended Transfer option.

During Consultation the new active call is shown at the top and when a call is active (established) the call is shown with dark gray color.

### 5.6.2.13 How to Alternate between two Parties

#### Prerequisites

You are talking to one party, while keeping another party on hold, e.g., during a consultation.

#### Step by Step

Click **Toggle/Connect** to switch from one user to another.

### 5.6.2.14 How to Transfer a Call

#### Step by Step

- 1) If you receive an incoming call, click on the **Deflect Call** button, enter the phone number you want to transfer the call and click on **Transfer**.
- 2) If you are on an active call, click on the **Blind Transfer** button, enter the phone number you want to transfer the call and click on **Transfer**.

### 5.6.2.15 How to Pick up a Call from the Favorites List

A call pickup option appears on mouseover in case one of the favorites receives a call.

#### Prerequisites

The receiver is a favorite contact

The receiver is in an internal directory

Blinking circle around user image (ringing status). The color of the circle is yellow for internal callers and orange for external callers.

---

**NOTICE:** If the receiver is in UC Suite mode and is a networking contact then call pick up is not supported because of lack of hook status events.

---

#### Step by Step

- 1) Click on the **Favorites** icon in the main menu.
- 2) Put the mouse pointer over the favorite contact.
- 3) Click on green button to pick up the call.

### 5.6.2.16 How to Initiate a Conference During a Call

#### Prerequisites

You are talking to one party, while the other party is on hold.

#### Step by Step

In the Call window, click on the **Conference** button.

### 5.6.2.17 How to End a Call

#### Step by Step

Click on the **End Call** button.

### 5.6.2.18 How to Dial a Number Manually

#### Step by Step

Enter the phone number in dialable format or in canonical format in the **Search / Dial** field and press the `Enter` key.

---

**NOTICE:** In UC Smart, if you enter a dialable number, it is recommended not to use a seizure code for external line. A pop-up window appears, asking you if the number is internal or external.

In UC Suite, when the number is in a dialable format, the access code is added automatically from the system, from the default trunk.

---

### 5.6.2.19 How to use DTMF tones during an active VoIP call

During an active VoIP call the UC Suite user can enter DTMF digits. A DTMF dialpad is available by pressing CTRL+D on the keyboard. A popup windows opens in the center of the main display and the user is able to move the window to his/her preferred position. This position is stored and used when the application opens next time.

#### Prerequisites


UC Suite client

Active VoIP call

#### Step by Step

- 1) Press the **CTRL+D** key on the keyboard

2) An on screen keyboard appears



3) Use this keyboard to enter DTMF tones.

---

**NOTICE:** The on screen keyboard is minimized by pressing



## 5.7 Voicemail

myPortal @work organizes voicemails under the **Conversations**.

When you receive a voicemail for an unanswered call, a message with the voicemail is attached automatically in the respective conversation entry. The title of the message is **Voice message**

Played voice messages are deleted after 30 days by default.



---

**NOTICE:** Voicemail control is only available for UC Smart mode

---

### Identification of Voicemails

The entries are identified as follows:

Symbol	Description
	New voice message
	Played voice message

---

**NOTICE:** This feature is available with the UC Smart and UC Suite solutions.

---

## 5.7.1 How to Listen to a Voice Message on the Phone

### Prerequisites

Your presence status is **Office**.

UC Smart mode

### Step by Step

- 1) Click on the **Conversations**.
- 2) Click the entry which contains the voicemail.
- 3) Select a phone number under **Play via <your phone number>** in the Details view and click on the play icon.

## 5.7.2 How to Activate or Deactivate Message Recording

### Prerequisites

UC Smart mode

### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Voicemail** tab.
- 4) Select one of the following options:
  - a) If you want to enable callers to leave a message after the greeting, select the **Recording** check box.
  - b) If you do not want callers to leave a message after the greeting, clear the **Recording** check box.
- 5) Select the desired greeting in the **Greeting** drop-down list.

## 5.7.3 How to Change your PIN for the Voicemail Box

### Prerequisites

This function is only available after you have changed the preassigned PIN (Standard PIN: 123456) for your voicemail box.

UC Smart mode

### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Voicemail** tab.
- 4) Click on **Change PIN**.
- 5) Enter your old PIN for the voicemail box under **Old PIN**.

- 6) Then enter a new PIN for your voicemail box under **New PIN** and **Repeat PIN**, respectively.

---

**NOTICE:** The code number consists of a six digit sequence. Repeated digits (e.g., 333333) and digit sequences in ascending or descending order (e.g., 987654) are not allowed.

---

## 5.7.4 Notification Service for Messages

The system can optionally notify a UC Smart user about a new voicemail by e-mail.

### Prerequisites for the Notification Service

- The delivery of e-mails (e-mail forwarding) has been configured by the administrator in the system.
- The user's e-mail address must be known to the system. The administrator can import all e-mail addresses in the WBM during the initial installation via an XML file or enter an e-mail address for each user in the UC Smart Assistant. Alternatively, users can specify their own e-mail addresses in their myPortal @work client.
- A Voicemail licence is assigned to the user.
- The **Send voicemail to e-mail** feature is enabled. The administrator can activate the feature for each user in the UC Smart Assistant. Alternatively, users can activate the feature themselves in their myPortal @work client.

The myPortal @work user receives an e-mail with the voicemail as an attached WAV file (16 bit, mono), together with the date and time of receipt, duration of the voicemail and, if available, the phone number and name of the sender.

## 5.8 Conferences

In a conference, multiple participants (including external parties) can communicate with one another at the same time. The Conference Management function enables you to quickly and easily host conferences and also to schedule them in advance.

### Phone-controlled and Application-controlled Conferences

As a subscriber, you can initiate conferences both via the phone and via the myPortal @work application.

You can initiate a phone-controlled conference in the following ways, and then control that conference via the phone:

- Call the desired conference participant and connect him or her to the conference
- Extend a consultation call into a conference
- Extend a second call into a conference

You can initiate, control and manage application-controlled conferences via the Conference Management of myPortal @work. A Conference license is required for the use of Conference Management.

Differences between the conference types:

---

**NOTICE:** The application controlled Conference is available in UC Smart mode only.

---

	Phone-controlled conference	Application-controlled conference
Direction of connection setup from the viewpoint of the system	<ul style="list-style-type: none"> <li>Outbound</li> </ul>	<ul style="list-style-type: none"> <li>Inbound (dial-in by the participant)</li> </ul>
Authentication of conference participants	-	<ul style="list-style-type: none"> <li>Personal PIN (conference ID)</li> <li>Guest PIN (optional)</li> </ul>
Predefined invitation to the conference participants	-	<ul style="list-style-type: none"> <li>Conference Name</li> <li>Dial-in number (MeetMe)</li> <li>Personal PIN (conference ID)</li> <li>Guest PIN (optional)</li> </ul>
Max. number of participants per conference	8	16

### Application controlled Conference

Application controlled conferences are created as permanent conferences. The conference can be used as needed. Conferences do not occupy any conference channel so long as no participant has dialed into the conference. The order of dialing in determines the assignment of the conference channels.

### Moderators

The initiator of a conference is automatically the moderator and can:





- Create, edit and delete scheduled conferences.
- Add and remove conference participants.  
Removed participants do not remain in the conference.
- Disconnect conference participants.  
Disconnected participants can dial back into the conference.
- Specify another internal participant on the same node as the moderator
- Leave the conference without ending it immediately.  
If the last moderator leaves the conference, it ends after 5 minutes.
- End active conferences.
- Send predefined invitations to all or individual conference participants.

All internal participants within a node can be moderators. However, a conference license is required for each user that is defined or assigned as moderator.

Conference participants whose contact details were entered manually are treated as external participants and cannot be set as moderators.

**Conference Participants**

Conference participants can leave the conference and dial-in again. In addition, they can participate in a web collaboration session has already been started. As long as a conference has only one participant, the participant hears music on hold. The maximum number of external conference participants is limited, inter alia, by the number of available trunks.

Symbol	Status	Description
	Inactive	The participant is not in the conference. No conference channel is used.
	Dialing in	The participant is just dialing into the conference.
	Waiting	The participant is in the conference and is currently listening to music on hold.
	Active	The participant is in the conference. A conference channel is in use.

**Automatic Termination without a Moderator**

If the last moderator leaves the conference, the other participants are notified with an info text that the conference will end after about 5 minutes.

**Notification of Conference Participants**

The moderator can send all or some conference participants an invitation by email. This requires an email program to have been installed on the client PC. Known email addresses are automatically added to the distribution list. In an invitation to all conference participants, only the general guest PIN (if allowed) is included; for individual invitations, the personal PIN is also sent.

Alternatively, a predefined invitation text can be copied to the clipboard for further use in other programs (e.g., a chat program).

---

**NOTICE:** This feature is only available with the UC solution UC Smart

---

**5.8.1 How to Create a Conference**

**Step by Step**

- 1) Click on the **Conference**.
- 2) Click on the **New Conference** button. The conference is created with you as the moderator.
- 3) Enter a name for the scheduled conference.
- 4) If you want other participants who are not listed in the scheduled conference to also be able to dial into the conference, select the **Allow dial-in via guest PIN** check box.

- 5) Add further participants:
- Click on the **Add Participants** button.
  - To add a participant from the directories, enter either the phone number or name of the participant in the **Add participant from directory** field. Select the participant and click on **Add**.
  - To add an external participant, enter the data of the participant in the **Add external participant** field.
  - Repeat steps a through d for further participants.
  - Click on close button once you have added all the participants.

---

**NOTICE:** You can also add further participants to the conference later via the Favorites or a search in directories.

---

- 6) Specify the moderator for the conference:

As the initiator of the conference, you are automatically a moderator. If needed, you can specify further conference participants as moderators. The prerequisite for this is that the selected participant has a conference license. If you do not want to be a moderator yourself, you can reset your moderator status. However, there must be at least one conference participant set as a moderator of the conference.

- If you want to set further participants as a moderator, click on the **Set moderator status** button in the desired conference participant entry.
- If you want to reset your own moderator status, click on **Reset moderator status** button in your conference participant entry.

---

**NOTICE:** You can delete conferences and add or remove participants only as a moderator.

---

- 7) Send invitations if required:

You can send an invitation to all or individual conference participants. An email program must be installed on the client PC for this purpose. Known email addresses are automatically added to the distribution list. You can copy the invitation text to the clipboard.

- If you want to send an invitation to all conference participants, click on the **Send invitations to all** button. The email program is opened, and an email with the dial-in number and guest PIN (if allowed) is created.
- If you want to send an invitation to one conference participant, click on the **Invite by email** button in the desired conference participant entry. The email program is opened, and an email with the dial-in number, the personal PIN (conference ID) and guest PIN (if allowed) is created.
- If you want to copy the invitation text, click on the **Copy invitation** button.

## 5.8.2 How to Display a Conference

### Step by Step

- Click on the **Conference**.
- All conferences, in which you are a conference participant, are displayed on the list view. The active conferences are displayed on top of the list view.  
Conferences in which you are a moderator are marked with a green star.

- 3) Click on the desired conference to display the data and the participants of the conference in the details view.

Moderators are marked with a green star.

### 5.8.3 How to Rename a Scheduled Conference

#### Prerequisites

You are a moderator of the conference that you want to rename.

#### Step by Step

- 1) Click on the **Conference**.
- 2) Click on the conferences you want to rename.
- 3) Click in the header of the scheduled conference on the name of the conference.
- 4) Change the name of the conference.

### 5.8.4 How to Dial into a Conference

#### Prerequisites

You are a participant of a scheduled or active conference.

You can dial into a conference via myPortal @work or directly from your phone. To dial in from the phone, you will need the dial-in number and your personal PIN (conference ID). This data may have been sent to you by email, for example.

#### Step by Step

- 1) Click on the **Conference**.
- 2) Select the conference you want to dial.
- 3) Call the **India number** of the conference and enter the PIN of the conference.

If you are the first participant of a scheduled conference, you will hear music being played until another participant dials in.

Once you dial into the conference a Conversation entry is created automatically with the details of the conference.


### 5.8.5 How to Add Conference Participants

#### Prerequisites

You are a moderator of the conference.

#### Step by Step

Add the conference participants by one of the following methods:

- Add a participant from the Favorites:  
Click in the Favorites and select the participant you want to add. Click on  and then click on the **Add user to conference** symbol for the desired participant. Select the conference to which the participant is to be added and confirm this with **OK**.
- Add a group from the Favorites:  
Click in the Favorites on the **Add group to conference** symbol for the desired group. Select the conference to which the group members are to be added and confirm this with **OK**.
- Add external participants:  
Click on **Conference** and then on the desired conference. Click on the add participant button. Enter the requested information for the participant in the **Add external participant** area. Click **Add** to confirm your selection.
- Add a participant from directories:  
Enter either the phone number or name of the participant in the **Add participant from directory** field. Select the participant and click on **Add**.

## 5.8.6 How to Disconnect a Conference Participant

### Prerequisites

You are a moderator of an active system conference.

### Step by Step

- 1) Click on the **Conference**.
- 2) Click on the desired active conference.
- 3) Click on the **Disconnect user** button in the conference participant entry you want to disconnect.

The connection to the participant is cleared, but the participant remains in the participant list of the active conference and may dial-in at any time.

## 5.8.7 How to Remove Conference Participants

### Prerequisites

You are a moderator of a scheduled application controlled conference.

### Step by Step

- 1) Click on the **Conference**.
- 2) Click on the desired conference.
- 3) Click on the **Remove user** button in the conference participant entry you want to disconnect.

## 5.8.8 How to Delete a Scheduled Conference

### Prerequisites

You are a moderator of the scheduled conference.

### Step by Step

- 1) Click on the **Conference**.
- 2) Click on the desired conference.
- 3) Click on the **Delete conference** button in the details view.

## 6 Configuration

You can configure myPortal @work in accordance with your requirements.

Some configuration items in the settings menu and associated dialogs are displayed depending on the configuration of the communication system, e.g. MULAP number configuration or Mobility feature configuration.

### 6.1 Personal Preferences

You can enter personal preferences for myPortal @work such as your e-mail address or an additional phone number, for example, and even add a picture of yourself.

The image you provide will be displayed to other internal subscribers in directories and favorites, for example. Your image can also be displayed on system telephones with a large color display (only with the HFA variants).

#### 6.1.1 How to Edit your Contact Data

The contact data you specify is made available to other subscribers in directories and favorites, for example.

##### Step by Step

- 1) Click on your name.
- 2) Click on the **Settings** tab.
- 3) Click on the **Appearance** tab.
- 4) Edit the **Mobile Phone Number**, **Home/External phone number** and **My Email Address** fields if required. Phone numbers should be entered in canonical format (e.g., +49891234567).

#### 6.1.2 How to Provide your own Image

##### Prerequisites

You have an image with at least 40 x 40 pixels in the JPG or PNG file format. The file size must be no larger than 512 kB.

##### Step by Step

- 1) Click on your name.
- 2) Click on the **Settings** tab.
- 3) Click on the **Appearance** tab.
- 4) In the Profile Image section click on **Update** and select the image you want to upload. The image is automatically scaled to 200 x 200 pixels.

---

**NOTICE:** This functionality is only supported in myPortal @work UC Smart mode.

---

### 6.1.3 How to Delete your own Picture

#### Step by Step

- 1) Click on the icon for your presence status.
- 2) Click on the **my image** tab.
- 3) Click **Delete**.

## 6.2 Dialing Hotkey Settings

The hotkey for speed dialing and its functionality can be configured.

However, the functionality can only be used with myPortal @work. The hotkey for speed dialing is set up in myPortal @work as a single key or a key combination.

Since the configured hotkey may have already been assigned a function in the application in which the phone number is marked (e.g., Ctrl + P to open the Print dialog), the speed-dial function behaves by default as follows:

After the user has marked the phone number in the application and entered the configured hotkey, the hotkey is passed on to the application.

As soon as the phone number has been passed to myPortal @work, the dialing is performed.

### 6.2.1 How to Define a Hotkey for Speed Dialing

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Appearance** tab.
- 4) Enter a key or a key combination of your choice in the **Dialing hotkey** field based on the following table:

Key combination	Notes
<b>F1 and F12</b>	Not allowed
<b>F2 - F11</b>	Allowed
<b>Shift + &lt;Number/Letter&gt;</b>	Not allowed
<b>Shift+F1 and Shift+F12</b>	Not allowed
<b>Shift+F2 - Shift+F11</b>	Allowed
<b>Ctrl+c, Ctrl+v, Ctrl+z ,Ctrl+r, Ctrl +a,Ctr+x</b>	Not allowed
<b>Ctrl + &lt;Number/Letter&gt;</b>	Allowed
<b>Ctrl + Alt + &lt;Number/Letter&gt;, Ctrl + Shift + &lt;Number/Letter&gt; (Three keys combination)</b>	Allowed

## 6.3 Programming the Function Keys of the Telephone

You can customize the function keys of your telephone device and any available key module or Busy Lamp Field (BLF) to suit your requirements via the UC client with a web application.

This applies to both the predefined function keys and the other function keys, but not the local application keys (**Local App.**). The user interface for key programming is opened in the same language as the UC client, if available; otherwise, in English.

---

**NOTICE:** The function keys of a SIP phone, an ISDN phone or an analog phone cannot be programmed with the UC Client.

In the case of phones with a display, you can also program some function keys directly at the phone.

---

### Programming Function Keys on Different Levels

You can program the function keys on two levels: the first level can be assigned all the offered functions, and the second level can be assigned external phone numbers. The Shift key must be configured on the phone in order to use the second level. The LED of the function key is always assigned to the first level.

---

**NOTICE:** When switching from a physical device to VoIP and back, programmed function keys are not deleted.

---

### 6.3.1 How to Program the Function Keys of the Telephone

#### Step by Step

- 1) Click on your name and then click on **Settings**.
- 2) Click on the **Appearance** tab.
- 3) Click on the **Key Programming** link. A window for programming the function keys of the telephone device opens in the web browser.
  - a) If a message such as `There is a problem with this website's security certificate.` appears, click on **Continue to this website**.
- 4) Under the phone icon, Click on the key area that you want to edit.
- 5) In the detailed view of the key area, click on the key icon at end of the corresponding row. The key icon goes red and indicates that the function is active for programming.
  - a) If you want to display details on the current function of a key, move the mouse pointer over the label field to the left of the key.

- 6) Select the desired function from the **Choose Function** drop-down list.
  - a) If a function requires additional information (parameters), select these details or enter the required data.

---

**NOTICE:** Select the **Shift Key** function for a function key to access a second level where you program external phone numbers.

---

- 7) Click **Save**.
- 8) If you selected a system phone with automatic key labeling, you can enter the text that should appear in the display of the function key in the **Labeling** column.
- 9) If you have programmed a function key as the **Shift Key**, select the check box **2. Level**. Enter the external phone numbers as described under steps 7 to 9.
- 10) If you want to program further function keys, repeat steps 5 through 10.
- 11) Close the web browser window for key programming.
- 12) Click in the **Appearance** tab on **OK**.

## 6.4 General Settings

You can specify general settings for myPortal @work such as the date format or the address of the server.

### Server Connections

If a subscriber can be reached at different locations (e.g., via a LAN in the office and via the Internet), up to 4 server connections can be configured. The server used is OpenScape Business UC Server.

### 6.4.1 How to Change your myPortal @work Password

#### Prerequisites

This function is only available when the connection to the system is encrypted (https).

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on **User account** and then click on **Change Password** button.
- 4) In UC Smart mode
  - a) Enter your old password under **Old password** field.
  - b) Enter your new password in accordance with the security policies under **New password** and **Repeat password**.

---

**NOTICE:** In the UC Smart mode the password must be between 8 and 16 characters long and must include at least one uppercase letter, one lowercase letter, one digit

and one special character. Make sure that you remember your new password.

- 
- c) Click on **OK**.
- 5) In UC Suite mode
- a) Enter your new password in accordance with the security policies under **New password** and **Repeat password**.

---

**NOTICE:** In the UC Suite mode the password must consist of only digits and include at least six digits. Additionally, the password's maximum number of repeated characters is two and the maximum number of sequential characters is three and also the account name (reversed or not) cannot be part of the password. Make sure that you remember your new password.

---

- b) Click on **OK**.

## 6.4.2 How to Enable or Disable the Automatic Login of myPortal @work

### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Appearance** tab.
- 4) Select one of the following options:
  - If you want as a myPortal@work user to login automatically, select the **Automatic login** check box.
  - If you do not want myPortal@work to login automatically, clear the **Automatic login** check box.
  - If you want myPortal@work to start automatically when you turn on your computer select the **Start application on launch** check box.

## 6.4.3 How to Select the User Interface Language

### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Appearance** tab.
- 4) Select the desired language in the **Language** drop-down list.

myPortal @work changes the language automatically.

## 6.4.4 How to Select the Date Format

### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.

- 3) Click on the **Appearance** tab.
- 4) Select the desired format from the **Date format** drop-down list.

### 6.4.5 How to Configure the Pop-up Visibility for Active Calls

#### Step by Step

- 1) Click on your user name.
- 2) Click on **Settings > Appearance**.
- 3) Select one of the following options in the **Popup visibility** drop-down list:

Option	Description
<b>Always visible</b>	The pop-up window always appears
<b>5 seconds</b>	The pop-up window appears for 5 seconds
<b>10 seconds</b>	The pop-up window appears for 10 seconds
<b>When minimized</b>	The pop-up window appears only when minimized or when pin window is disabled
<b>Never visible</b>	The pop-up window never appears

### 6.4.6 How to Add a Personal Contact

#### Prerequisites

UC Smart mode

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click in the **Personal contacts** and then click on the **Add personal contact** icon.
- 4) Fill in the fields in the **Add to personal contacts** window.
- 5) Click on **OK**. The contact appears in the Personal Contacts.  
myPortal@work in UC Smart mode, supports adding or importing 3000 contacts.

### 6.4.7 How to Import Contacts into the Personal Contacts

#### Prerequisites

An appropriate XML file in UTF-8 encoding or a CSV file with personal contacts is available. A template for this is available via the Download Center in the WBM of the communication system and can be edited with Microsoft Excel, for example.

**Step by Step**

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **Personal contacts**.
- 4) For importing a Csv/XML file, select the encoding of the Csv/XML file under **File encoding CSV/XML import drop-down list**.
- 5) Click on the **Import personal contacts from Csv/XML** icon.
- 6) Navigate to the storage location of the desired XML or CSV file and click **Open**. Once the import is complete, you will be informed of the result in the window.

## 6.4.8 How to Edit the Server Settings

---

**NOTICE:** Do not change the server settings unless you are instructed to do so by the administrator of your communication system. You cannot use myPortal@ work with an invalid server address.

---

**Step by Step**

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **User account** tab.
- 4) Select the right Server connection (1-4).
- 5) Enter the IP address or name of the communication system (e.g., 192.168.1.2) under **Server IP Address**.
- 6) Under **Server Port Address**, enter the port used by the UC client to communicate with the communication system (default: 8802).
- 7) Click **Reconnect**.

## 6.4.9 How to Configure Additional Server Connections

This configuration is used for switching between different users.

**Step by Step**

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **User account** tab.
- 4) Under **Server Connections**, select the index for the next available server connection.
- 5) Enter a user name for the server connection under **Username**.
- 6) Under **Password**, enter the password for the server connection in accordance with the security policies.

---

**NOTICE:** The password must be between 8 and 16 characters long and must include at least one uppercase

letter, one lowercase letter, one digit and one special character. Make sure that you remember your new password.

- 7) Optional for MULAP: Enter the call number of the associated phone in the **Controlled device** field.  
Prerequisite: Your user name represents a MULAP. Ask your system administrator in case of doubt.
- 8) Only for Mobility Users: Select one of the following options in the **Dial Mode** drop-down list:
  - If you want to initiate outbound calls with your office phone, select **Associated dial**.
  - If you want to initiate outbound calls with your mobile phone, select **Callback preferred**.
- 9) Enter the IP address or the domain name of the server in the **Server IP Address** field and the port number (default: 8802) in one line separated by a colon (:).
- 10) Click **Reconnect**.
- 11) If you want to configure additional server connections, repeat the previous steps.

---

**NOTICE:** Server configurations are automatically synchronized and are saved to the login screen by starting myPortal @work.

---

### 6.4.10 How to Enter the Call Number for the Associated Phone (for a MULAP)

#### Prerequisites

Your user name represents a MULAP.

The call number for the associated phone was communicated to you by your administrator.

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **User account** tab.
- 4) Enter the call number of the associated phone in the **Controlled Device** field.
- 5) Click on **Reconnect**.

### 6.4.11 VoIP in myPortal @work

myPortal @work provides an embedded VoIP client which enables the user to make and receive VoIP calls. It can be used with both UC Smart and UC Suite solutions. No physical telephone device needs to be connected in order to make

VoIP calls through myPortal @work. When VoIP functionality is activated, all telephony calls are controlled by the embedded VoIP telephony client.

---

**NOTICE:** The VoIP client can be activated and used only if the appropriate prerequisites for Voice over IP telephony have been fulfilled by the OpenScape Business System administrator.

---



---

**NOTICE:** When VoIP functionality is activated, any keys you have previously programmed on your physical telephone device are not deleted, as myPortal @work is considered to belong to the same device family as your desk phone.

---

In case of VoIP, additional settings are required for:

- The SDP negotiation process, see [How to Enable Simplified SDP Negotiation](#) on page 56.
- The selection of Audio input, Audio output and ringing device, see [How to manage audio settings](#).

In case there are VoIP problems or the administrator asks:

- To check the NAT type, see [How to Check NAT type](#) on page 57.
- To add a STUN server, see [How to Add a STUN server](#) on page 57.

### 6.4.11.1 How to Enable VoIP

With myPortal @work you can make and receive VoIP calls.

#### Prerequisites

In order to make VoIP calls through myPortal @work, you must not connect a physical device.

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **VoIP** tab.
- 4) If you want to enable VoIP calls, switch **VoIP disabled** to ON (green).  
By default it is disabled (grey).

If the VoIP is enabled, the **Show VoIP icon in title bar** is also enabled.

If the VoIP is disabled, you can decide if you want to see the VoIP settings button on the title bar or not.

If the configuration is not adequate (e.g. missing license, not compatible controlled device), **VoIP disabled** is auto-deactivated.

Alternatively, you can quickly navigate to VoIP settings, by clicking on the VoIP button and then click **VoIP settings**. When you enable VoIP, you also have to manage audio settings (see [How to manage audio settings](#)).

---

**NOTICE:** In case you are in a MULAP, tap on **Controlled device** to select your WebRTC phone number. For the specific number to choose, please ask the system's administrator.

---

### 6.4.11.2 How to Enable Simplified SDP Negotiation

To reduce payload delays in VoIP calls with myPortal @work that are caused by RE-Invite SIP messages from the ITSP side, it is recommended to enable **Codec Preselection**. This simplifies the SDP negotiation process by limiting the codec options within the SDP answer and therefore preventing the RE-Invite SIP messages from the ITSP side.

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **VoIP** tab.
- 4) Click on **Advanced Settings**.
- 5) If you want to enable simplified SDP negotiation, switch **Codec Preselection** to ON (green).  
By default it is disabled (grey).

---

#### NOTICE:

If you enable **Codec Preselection**, then codec limitation will be applied for all VoIP calls within myPortal @work.

**Codec Preselection** must only be enabled when there are payload delays that are caused by RE-Invite SIP messages from the ITSP side.

---

### 6.4.11.3 How to Manage Audio settings

You can choose which devices you want to use for voice communication and possibly a separate audio device for the ringing output of incoming calls.

#### Prerequisites

The appropriate audio devices have to be supported and enabled within the Microsoft Windows OS.

#### Step by Step

Click on the **VoIP Settings** button at the top of myPortal @work and then:

- a) Under **Microphone** area, choose the device or headset you want to use for calls and the selected device will be highlighted.
- b) Under **Audio output** area, choose the audio device or headset you want to use for audio calls in myPortal @work and the selected device will be highlighted.
- c) Under **Ringing device** area, choose the audio device or headset that you want to ring for incoming calls and the selected device will be highlighted.

---

**NOTICE:** When a new device is connected/disconnected, the **VoIP Settings** list is updated automatically and the **VoIP settings** button is blinking.

---

#### 6.4.11.4 How to Check NAT type

##### Prerequisites

VoIP is enabled.

When there are problems with VoIP or when you are asked by the administrator, you can use the following procedure to check the NAT type.

##### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **VoIP** tab.
- 4) Click on **Advanced Settings**.
- 5) Click on **Check NAT type**.  
A pop-up window appears with the title **NAT type detection** and a progress bar showing the operation is loading.
- 6) Once the operation completes, a new pop-up window appears with one of the following messages depending on the NAT type detected:
  - **NAT Type: simple**  
A message informs the user that VoIP services can be used without restrictions.
  - **NAT Type: Symmetric**  
A message informs the user that VoIP services behind a Symmetric NAT are not supported over public networks. The client may still be used in a local network.
  - **NAT Type could not be detected.**  
A message informs the user that the request is taking too long and timed out, or UDP appears to be blocked.

#### 6.4.11.5 How to Add a STUN server

##### Prerequisites

VoIP is enabled.

myPortal @work is set up with a default STUN server that is used for VoIP communication. When there are problems with VoIP or when you are asked by the administrator, you can use the following procedure to add a STUN server.

##### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.

- 3) Click on the **VoIP** tab.
- 4) Click on **Advanced Settings**.
- 5) Click on **Check ICE status** to check if the STUN server can be reached.

---

**NOTICE:** The default STUN server will not appear in the **ICE servers** list and you can't remove it.

---

- 6) Click on **Add server** to enter a STUN server.

---

**NOTICE:** The administrator can provide you with the specific server addresses to add.

---

If the server address is valid, it is added to the list.

If there is any problem, the notification `Failed to add the server.` Please check your environment appears.

If the entered server is already present in the list, the notification `Server is already present` appears.

## 6.4.12 How to Configure the Headset Integration

The Headset Integration allows you to control your calls using your headset buttons.

The following call controls are supported for Jabra and Plantronics headsets:

- Answer incoming call
- Reject or end call
- Mute/unmute call

Additional call controls are supported depending on your headset, like:

- Hold / retrieve call
- Toggle between calls.

---

**NOTICE:**

For parallel calls, the handling of headset buttons (answer/reject call) is not feasible.

---

### Prerequisites

Connect your headset to your computer.

For Plantronics, download the application: <https://www.poly.com/ca/en/support/downloads-apps/hub-desktop>.

### Step by Step

- 1) Enable VoIP calls (see [How to enable VoIP](#)).
- 2) On the **VoIP** tab, enable the **Jabra Headset Integration** or the **Plantronics Headset Integration** depending on your headset device.  
Once a connection to your device is successfully established, the message: `Connected with <device model>` appears on the screen.

- 3) Select your device in the VoIP settings, if not already selected (see [How to manage audio settings](#)).

### 6.4.13 How to Change the Dialing Mode (only for Mobility Users)

#### Prerequisites

Mobility feature has been enabled for you within the Communication system.

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **User account** tab.
- 4) Select one of the following options in the **Dial Mode** drop-down list:
  - If you want to initiate outbound calls with your office phone, select **Associated dial**.
  - If you want to initiate outbound calls with your mobile phone, select **Callback preferred**.
- 5) Click on **Reconnect**.

### 6.4.14 How to Reconnect with myPortal @work

#### Step by Step

- 1) Click on your name.
- 2) Click on **Settings**.
- 3) Click on the **User account** tab.
- 4) Only if you want to use another server connection: select the desired server connection under **Server connections**.
- 5) Click on **Reconnect**.

# Index

## A

- absence [20](#)
- ad-hoc conference [41](#)
- application-controlled conference [40](#)
- authentication
  - conference participant [41](#)

## C

- call
  - answer [31](#)
  - end [31](#)
  - pick up for another subscriber [31](#)
- call functions [31](#)
- call number format [30](#)
- CallMe [24](#)
- CallMe service [24](#)
- canonical call number format [30](#)
- compact view [13](#)
- conference [31](#), [41](#)
- conference management [40](#)
- conference, phone-controlled [40](#)
- configuration [47](#)
- connection status [20](#)
- consultation hold [31](#)
- contact [25](#)

## D

- date format [47](#)
- dial [31](#)
- dial-in number
  - conference [41](#)
- dialable call number format [30](#)
- dialing a number [31](#)
- directory
  - make call [31](#)
- disconnect [31](#)

## E

- e-mail
  - notification [40](#)
- e-mail address [47](#)
- email
  - invitation to conference [41](#)
- event [47](#)
- exit [11](#)

## F

- favorites list [25](#)

- Favorites list
  - make call [31](#)
- first steps [11](#)
- foreground [47](#)
- forward [31](#)
- functions
  - myPortal Smart [8](#)

## G

- group [25](#)

## I

- invitation
  - conference [41](#)
- IP address [47](#)

## J

- journal
  - call [31](#)

## K

- key programming [49](#)

## L

- language [47](#)

## M

- main window [13](#)
- minimized view [13](#)
- Mobility Entry stations
  - conferencing [41](#)
- myPortal Smart
  - functions [8](#)

## N

- Normal view [13](#)
- notification
  - voicemail [40](#)
- notification service [40](#)

## P

- password [11](#)
- permanent conference [41](#)
- phone number [47](#)
- picture [13](#), [47](#)
- port number [47](#)

- presence [13](#), [20](#)
- presence status [20](#)
  - visibility [20](#)
- presentation [47](#)
- profile [13](#)
- program settings [47](#)
- protocol [47](#)

## R

- redialing [31](#)
- redirect [31](#)

## S

- scheduled conference [41](#)
- screen pops [13](#)
- server address [47](#)
- setup [47](#)
- start [11](#), [47](#)
  - automatic [47](#)
- symbol [13](#)

## T

- tab [13](#)
- teleworking [24](#)
- toggle/connect [31](#)
- tool tip [13](#)
- transfer [31](#)

## U

- unified communications [18](#)
- user interface [13](#)
  - language [47](#)

## V

- view [13](#)
- virtual conference room [41](#)
- visibility
  - window [47](#)
- voicemail box [31](#)

## W

- WAV file
  - notification [40](#)
- window
  - visibility [47](#)

